













SPARE PARTS LIST

BRUSHCUTTERS/CLEARING SAWS

323 R from 2014-12 -

T 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
ACCESSORIES




ACCESSORIES

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	531 00 92-48	FILTER OIL		1
2	502 28 59-01	HOUSING		1
3	501 60 02-03	Отвертка		1
4	502 11 46-02	Ключ торцовый		1
5	502 21 58-01	WRENCH		1
6	537 35 36-01	Кольцо		1
7	537 13 04-02	KNOB		
8	537 35 01-01	Кольцо		6
9	725 23 31-51	SCREW		1
10	503 97 64-01	Смазка для кустореза Jon		1
11	537 31 29-01	Защита		1
12	503 73 40-01	FRONT PIECE		
13	503 73 41-02	FRONT PIECE		
14	502 02 28-02	Карабин подвески		1
15	537 21 62-01	ПОДВЕСКА КУСТОРЕЗА R		1
15	537 21 62-02	ПОДВЕСКА КУСТОРЕЗА R		


A 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
BEVEL GEAR



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 19 92-02	BEVEL GEAR		1	
2	503 85 63-01	Гайка		1	1
3	537 28 56-01	Кольцо-проставка		1	1
4	537 29 26-01	Патрубок глушителя 2094		1	1
5	537 23 49-01	CARRIER		1	1
6	735 31 28-10	Шайба		1	1
7	503 25 24-01	Съемник подшипника		1	1
8	738 21 98-00	Съемник подшипника		1	1
9	503 20 15-01	SCREW IHNM		1	1
10	503 20 14-12	SCREW IHSCFMO		1	1
11	503 20 07-25	SCREW IHSCFM		1	1
12	738 21 99-00	Съемник подшипника		1	1
13	738 21 99-02	Съемник подшипника		1	1
14	735 31 11-00	Шайба		1	1
15	735 31 25-10	Шайба		1	1
16	725 23 70-51	SCREW		1	
17	503 20 07-12	SCREW IHSCFM		1	
18	503 93 55-01	CLAMP.GUARD		1	

Спр. №	Код	Описание	Замечание	КОЛ Наб.	
1	576 01 98-01	Карбюратор	Hualong HQ-2, only option for US	1	
2	576 02 42-01	SCREW		2	1
4	576 02 36-01	КРЫШКА		1	1
5	576 02 24-01	DIAPHRAGM ASSY		1	1
6	576 02 30-01	SHAFT ASSY		1	1
7	576 02 41-01	SCREW		1	1
8	576 02 32-01	Рычаг воздушной заслонки		1	1
9	576 02 48-01	E-CLIP		1	1
10	576 02 31-01	Привод дросселя		1	1
11	576 02 35-01	BUSHING		1	1
12	576 02 33-01	Пружина		1	1
14	576 02 01-01	Вентиль		1	1
15	576 02 37-01	Прокладка		1	1
16	576 02 03-01	Гаечка 250PS		1	1
17	576 02 04-01	Привод дросселя		1	1
18	576 02 05-01	Пружина		1	1
19	576 02 06-01	Заглушка		1	1
20	576 02 28-01	Привод дросселя		1	1
21	576 02 29-01	BUSHING		1	1
22	576 02 07-01	MAIN NOZZLE		1	1
23	576 02 08-01	VALVE P351		1	1
24	576 02 43-01	SCREW		1	1
25	576 02 34-01	Пружина		1	1
26	576 02 47-01	BALL		1	1
27	576 02 23-01	ЦЕПЬ ДЛЯ ХАРВЕТЕРА		1	1
28	576 02 10-01	NEEDLE		1	1
29	576 02 11-01	NEEDLE		1	1
30	576 02 15-01	Сетка глушителя		1	1
31	576 02 27-01	Пружина		1	1
32	576 02 40-01	SCREW		1	1
33	576 02 26-01	THROTTLE		1	1
34	576 02 39-01	Мембрана		1	1
35	576 02 25-01	SHAFT ASSY		1	1
36	576 02 38-01	Прокладка		1	1
37	576 02 20-01	КРЫШКА		1	1
38	576 02 22-01	SCREW		1	1
39	576 02 44-01	SCREW		1	1
40	581 74 35-01	Набор прокладок		1	1
41	581 74 37-01	REPAIR KIT		1	1

J 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
CARBURETOR & AIRFILTER




CARBURETOR & AIR FILTER

323 R from 2014-12 -


Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	502 20 65-03	SCREW EHNM		1	
2	502 20 40-01	KNOB		1	
3	503 88 80-02	Продукция		1	
4	537 18 63-01	Фильтр воздушный		1	
5	503 21 75-16	SCREW IHSCFT		1	
6	503 96 25-01	Тяга в засл 3120K K1250		1	
7	503 91 09-01	Теплоизолятор		1	
8	503 22 65-04	Гайка		2	
9	503 94 26-01	Патрубок входной		1	
10	503 20 03-25	SCREW IHSCFM		2	
11	503 49 71-01	Прокладка		1	
12	503 28 34-01	Карбюратор		1	
12	576 01 98-01	Карбюратор	Hualong HQ-2, only option for US	1	
13	731 23 14-01	HEXAGON NUT		1	15
14	503 88 79-01	CAP		1	15
15	503 89 03-01	FILTERBLOCK ASSY		1	

S 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
CARBURETOR
(not for US)




Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	503 28 34-01	Карбюратор		0	
2	537 37 03-01	Вентиль		1	1
3	503 48 19-01	COLLAR		1	1
4	537 04 90-01	Привод дросселя		1	1
5	537 02 10-01	Пружина		1	1
6	537 37 03-01	Вентиль		1	1
7	503 48 18-01	SCREW		1	1
8	503 47 90-01	SCREW		1	1
9	537 01 98-01	Привод дросселя		1	1
10	503 47 89-01	COLLAR		1	1
11	503 48 05-01	SCREW		2	1
12	503 97 43-01	КРЫШКА		1	1
13	537 04 89-01	DIAPHRAGM		1	1, 41, 42
14	537 02 04-01	Прокладка		1	1, 41, 42
15	503 48 01-01	SCREW		1	1
16	503 48 00-01	PIN RETAINING SCREW		1	1, 41
17	503 66 59-01	Привод дросселя		1	1, 41
18	537 02 03-01	Пружина		1	1, 41
19	503 47 97-01	Вентиль		1	1, 41
20	537 02 08-01	Заглушка		1	1, 41
21	537 02 16-01	Набор колпачков карб.		1	1
22	503 48 08-01	Пружина		1	1
23	537 12 78-01	SCREW		1	1
24	537 02 16-01	Набор колпачков карб.		1	1
25	503 97 40-01	Шайба		1	1
26	537 02 06-01	SCREW		1	1
27	537 01 26-01	Пружина		1	1
28	537 01 25-01	BALL		1	1
29	503 53 57-01	STRAINER		1	1, 41
30	503 75 53-01	SCREW		1	1
31	537 01 97-01	Пружина		1	1
32	537 01 99-01	Вентиль		1	1
33	537 01 96-01	SHAFT ASSY		1	1
34	503 47 92-01	SCREW		1	1
35	537 02 00-01	Мембрана		1	1, 41, 42
36	537 02 01-01	Прокладка		1	1, 41, 42
37	537 02 02-01	КРЫШКА		1	1
38	503 47 96-01	SCREW		1	1
39	503 48 11-01	PIECE		1	1
40	537 02 07-01	SCREW		1	1
41	531 00 45-53	Набор прокладок		1	
42	531 00 45-52	Набор прокладок		1	

H 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
COVER



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	503 21 35-12	SCREW CCRPANT		2
2	537 10 44-01	ARM PROTECTION		1
3	503 21 68-20	SCREW IHSCFT		3
3	503 20 03-16	SCREW IHSCFM		3
4	537 35 33-14	Наклейка		1
4	537 35 33-16	Наклейка		1
4	537 35 33-17	Наклейка		1
4	537 35 33-15	Наклейка		1
4	537 35 33-20	Наклейка		1
4	537 35 33-24	Наклейка		1
4	537 35 33-22	Наклейка		1
4	537 35 33-23	Наклейка		1
4	537 35 33-26	Наклейка		1
5	503 97 21-01	КРЫШКА		1
6	503 96 13-01	SCREW		2
7	503 87 18-02	Крышка цилиндра		1
8	537 32 08-03	Теплозащитная прокладка		1
9	503 21 68-20	SCREW IHSCFT		1
9	503 20 03-16	SCREW IHSCFM		1

P 326
CRANK CASE




CRANKCASE & CLUTCHDRUM

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 30 96-01	COMPRESSION SLEEVE		1	
2	503 21 68-25	SCREW IHSCFT		2	1
3	537 04 12-07	Крышка сцепления		1	
4	537 07 36-01	Пружина		1	3
5	537 42 50-01	Пластина		1	3
6	537 04 11-03	Картер K950Ring		1	
7	503 21 66-18	SCREW IHSCFT		3	6
8	503 20 03-16	SCREW IHSCFM		7	6
9	503 20 03-16	SCREW IHSCFM		1	3

Q 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
CRANK SHAFT




CRANKSHAFT

323 R from 2014-12 -


Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	503 85 24-75	Коленвал			
2	503 94 02-03	Проставка		1	1
3	503 71 22-01	Игольчатый подшипник		1	1
4	503 94 02-03	Проставка		1	1

N 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
CYLINDER PISTON & MUFFLER



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 16 19-01	MUFFLER ASSY		1	
2	502 07 81-01	SCREW EHHFM		2	1
3	503 87 17-01	SPARK ARRESTER SCREEN		1	1
4	537 01 41-01	Прокладка		1	
5	503 20 07-35	SCREW IHSCFM		4	6
6	537 03 20-08	Цилиндр		1	
7	737 44 08-00	Шайба		1	9
8	503 71 22-01	Игольчатый подшипник		1	9
9	537 40 59-02	Поршень		1	6
10	537 40 62-01	Кольцо поршневое		2	9

L 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
FUEL TANK







FUEL TANK

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	503 93 66-01	PURGE		1	
2	537 04 24-01	Шланг топливный		2	5
3	503 91 18-02	Крышка топливного бака		1	
4	503 91 10-01	Опора		4	
5	537 06 86-02	Бак топливный		1	
6	503 73 58-01	BUSHING		2	5
7	544 32 50-01	Шланг топливный		1	5
8	504 02 24-01	Грузик топливного фильтра		1	5
9	503 44 32-01	Фильтр топливный с грузом		1	5

R 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
ACCESSORIES





GUARDS

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 29 95-01	SAW BLADE GUARD		1	
2	725 23 68-71	SCREW ЕННМ		2	1
3	537 04 75-01	Пластина		1	1
4	537 29 34-01	АДАПТЕР ДЛЯ КАНИС."АСПЕН"		1	1
5	502 27 22-01	SAW BLADE GUARD		1	1
6	503 21 75-16	SCREW IHSCFT		4	1
7	537 07 67-01	Защита от разброса 322L		1	
8	503 21 07-16	SCREW IHССТ		1	7
9	503 79 88-01	Нож для обрез.веток 80 см		1	7
10	503 93 42-02	COMBI GUARD		1	
11	503 21 07-16	SCREW IHССТ		1	10
12	503 79 88-01	Нож для обрез.веток 80 см		1	10
13	503 97 71-01	Защита от разброса 322L		1	
14	503 21 07-16	SCREW IHССТ		1	13
15	503 79 88-01	Нож для обрез.веток 80 см		1	13

G 323R, 325Rx
THROTTLE CONTROLS








HANDLE & CONTROLS

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 42 45-13	HANDLE SYSTEM		1	
2	503 21 66-16	SCREW IH SCT		2	1
3	537 41 90-01	MICRO SWITCH		1	1
4	537 16 07-01	STARTER THROTTLE LOC		1	1
5	506 49 77-01	THROTTLE CONTROL		1	1
6	537 17 43-01	Пружина		1	1
7	537 17 42-01	SPRING THROTTLE TRIG		1	1
8	537 16 03-02	Рукоятка		1	1
10	537 16 02-09	Рукоятка		1	1
11	503 22 10-13	HEXAGON NUT		1	1
12	503 20 07-35	SCREW IH SCFM		1	
13	537 42 44-01	Кабель 225H		1	
14	503 21 66-16	SCREW IH SCT		1	13
15	537 17 39-01	THROTTLE WIRE ASSY		1	13


U 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
HARNESS

Duo Balance




Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	503 99 61-01	Маркир.лента оранж/желтая		
2	503 99 61-03	Маркир.лента оранж/желтая		
3	537 27 59-01	Часть подвески кустореза		
4	502 02 28-01	Отпускной крючок к рулет.		
5	502 02 30-02	LOCK		4
6	586 34 10-01	Пружина		4
7	502 02 29-02	Отпускной крючок к рулет.		4
8	735 31 09-20	E-CLIP		4
9	537 11 35-01	Держатель		
10	503 99 61-03	Маркир.лента оранж/желтая		
11	503 99 61-01	Маркир.лента оранж/желтая		3
12	537 17 54-01	Часть подвески кустореза		3
13	537 27 59-01	Часть подвески кустореза		

M 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
IGNITION & CLUTCH






Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 04 58-01	КРЫШКА		1	
2	537 41 87-01	IGNITION MODULE		1	
3	537 23 96-01	Колпачок свечи зажигания		1	2
4	503 23 51-08	Свеча зажигания NGKBP7A		1	
4	503 23 51-11	Свеча зажигания NGKBP7A		1	
5	503 21 71-16	SCREW IHSCT		2	
6	503 84 29-02	SCREW		1	10
7	537 04 67-02	Шайба		1	10
8	503 81 60-01	Пружина сцепления		1	10
9	503 84 28-01	Колодка сцепления		2	10
10	537 03 22-01	Сцепление		1	
11	537 04 68-02	Шайба		1	10
12	731 71 16-51	HEXAGON NUT FLANGE		1	
13	537 24 96-02	Крыльчатка		1	

E 323R, 325Rx
SHAFT & HANDLE



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	725 23 86-51	SCREW EHNM		1	
2	502 20 38-01	KNOB		1	
3	503 72 29-01	КРЫШКА		1	
4	503 72 43-09	HANDLEBAR		1	
5	537 17 28-01	Передняя ручка 371К		1	4
6	537 17 29-01	КРЫШКА		1	4
7	731 23 14-01	HEXAGON NUT		1	4
8	503 75 00-01	HANDLEBAR BRACKET		1	4
9	502 21 12-01	Кронштейн 250PS		1	4
10	503 20 02-45	SCREW IHSCFM		1	4
11	503 88 88-01	TUBE		1	
12	502 21 12-01	Кронштейн 250PS		1	
13	503 88 23-01	Кронштейн		1	
14	503 20 07-16	SCREW IHSCFM		1	
15	503 94 10-01	Отпускной крючок к рулет.		1	
16	503 21 75-25	SCREW IHSCFT		2	
17	502 19 71-01	Гайка		1	
18	731 23 14-01	HEXAGON NUT		1	
19	537 23 48-01	Вал 323HD 325HD		1	
20	735 31 12-00	Шайба		1	
21	537 23 75-01	Барaban сцепления		1	
22	589 29 51-01	Наклейка		1	

K2 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
STARTER




STARTER

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	503 87 33-05	BRIDGE		2	
2	735 31 08-20	E-CLIP		1	1
3	503 87 36-01	Пружина		2	1
4	503 87 35-02	Собачка стартера		2	1
6	503 85 28-06	Стартер в сборе Partner			
7	537 37 93-02	Втулка 3120K K1250 K950		2	6
8	503 21 77-16	SCREW IH SCT		1	6
9	503 85 89-01	STARTER ROPE		1	6
10	537 00 84-01	Ручка стартера		1	6
11	503 96 49-01	Катушка стартера		1	6
12	503 85 87-02	Крышка стартера 2095		1	6
13	537 37 93-02	Втулка 3120K K1250 K950		1	6
14	537 03 41-01	Пластина		1	
15	503 20 03-16	SCREW IH SCFM		1	
16	503 21 66-18	SCREW IH SCT		1	
17	503 20 03-16	SCREW IH SCFM		2	

K1 323C, L, LD, R, RJ, 325CX, Lx, LDx, Rx, RJx
STARTER



STARTER

323 R from 2014-12 -

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	503 87 33-05	BRIDGE		1	
2	735 31 08-20	E-CLIP		2	1
3	503 87 36-01	Пружина		2	1
4	503 87 35-02	Собачка стартера		2	1
5	544 07 11-02	Стартер в сборе Partner		1	
6	503 21 77-25	SCREW IHSC T		1	5
7	544 03 87-02	Шайба приводная		1	5
8	544 03 88-02	Пружина		1	5
9	544 16 65-01	Катушка стартера 262		1	5
10	544 03 86-01	Катушка стартера		1	5, 9
11	503 85 90-01	Пружина		1	5, 9
12	537 35 34-04	Наклейка		1	
12	537 35 34-05	Наклейка		1	
12	537 35 34-07	Наклейка		1	
12	537 35 34-08	Наклейка		1	
12	537 35 34-14	Наклейка		1	
12	537 35 34-16	Наклейка		1	
12	537 35 34-12	Наклейка		1	
12	537 35 34-13	Наклейка		1	
12	537 35 34-18	Наклейка		1	
13	537 37 93-02	Втулка 3120K K1250 K950		2	
14	503 85 89-01	STARTER ROPE		1	5
15	537 00 84-01	Ручка стартера		1	5
16	537 41 16-01	Крышка стартера 2095		1	5
17	537 37 93-02	Втулка 3120K K1250 K950		1	5
18	503 21 68-20	SCREW IHSC FT		1	
18	503 20 03-16	SCREW IHSC FM		1	
19	537 03 41-01	Пластина		1	
20	503 21 66-18	SCREW IHSC T		1	
21	503 20 03-16	SCREW IHSC FM		1	