




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000001	Handlebar				
2	2	ZM000002	Lever				
3	2	ZM000003	Cap			Gomma; Rubber	
4	2	ZM000004	Lever connecting shaft				
5	1	ZM000005	Cable			Trazione; Traction	
6	1	ZM000171	Plate				
7	1	ZM000007	Cable			Rotore; Rotor	
8	1	ZM000173	Support				
9	1	ZM000174	Bush				
10	2	ZM000172	Plate				
11	4	ZM000006	Bolt				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000008	Belt cover				
3	1	ZM000010	Support				
4	1	ZM000011	Bushing				
5	1	ZM000012	Spring				
6	1	ZM000013	Pulley				
7	1	ZM000014	Pulley			Dentata; Toothed	
8	1	ZM000015	Belt			Dentata; Toothed	
9	1	ZM000016	Belt			Tipo V; V type	
10	1	ZM000017	Pulley				
2	1	ZM000377	Bushing				
11	1	ZM000378	Bushing				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000018	Lever				
2	1	ZM000019	Bracket				
3	4	ZM000236	Bearing				
4	1	ZM000021	Shaft				
5	1	ZM000022	Wheel				
6	1	ZM000023	Rubber ring				
7	2	ZM000024	Flange				
8	2	ZM000025	Screw				
9	2	ZM000026	Pulley				
10	3	ZM000229	Washer				
11	1	ZM000028	Shaft				
12	1	ZM000029	Wheel				
13	1	ZM000030	Spring				
14	1	ZM000031	Fork				
15	2	ZM000032	Sleeve				
16	1	ZM000033	Gear				
17	2	ZM000034	Complete wheel				
18	1	ZM000189	Bracket support				
19	1	ZM000193	Plate (guide)				
20	1	ZM000190	Plate				
21	1	ZM000194	Gear case assy				
22	1	ZM000101	Cover				
23	1	ZM000191	Support				
24	1	ZM000195	Support				
25	1	ZM000170	Knob				
26	1	ZM000196	Shaft				
27	1	ZM000192	Plate				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	ZM000035	Pulley				
2	1	ZM000036	Nut				
3	1	ZM000037	Spring				
4	1	ZM000038	Main board				
5	1	ZM000039	Spring				
6	1	ZM000040	Pulley				
7	1	ZM000041	Key				
8	1	ZM000042	Cover				
9	1	ZM000043	Bearing				
10	1	ZM000044	Knob				
11	1	ZM000045	Rod				
12	1	ZM000046	Main board				
13	2	ZM000047	Sliding block				
14	1	ZM000048	Plate				
15	1	ZM000049	Fan				
16	1	ZM000050	Oil seal				
17	1	ZM000051	Bearing				
18	1	ZM000052	Bearing				
19	1	ZM000053	Shaft				
20	1	ZM000054	Bearing				
21	2	ZM000055	Bushing				
22	2	ZM000056	Tiller dx				
23	1	ZM000057	Shaft				
24	2	ZM000058	Bushing				
25	2	ZM000059	Tiller sx				
26	2	ZM000060	Bushing				
27	2	ZM000061	Cover				
28	3	ZM000062	Rail plate				
29	3	ZM000063	Rail plate				
30	1	ZM000064	Snow chute			Orientabile; Adjustable	
31	1	ZM000065	Spring				
32	1	ZM000066	Bracket				
33	4	ZM000166	Self locking nut				
34	4	ZM000090	Pin				
35	1	ZM000218	Knob				
36	1	ZM000168	Shovel				
37	1	ZM000219	Cover dx				
38	1	ZM000220	Cover sx				
39	1	ZM000117	Gear				
40	2	ZM000115	Bushing				
41	2	ZM000116	Gasket				
42	1	ZM000248	Washer				
43	2	ZM000366	Washer				
44	8	ZM000114	Guard cap				
45	1	ZM000221	Plate (guide)				
46	2	ZM000229	Washer				
47	1	ZM000069	Case				
48	1	ZM000169	Shovel support				
49	1	ZM000379	Bushing				
50	1	ZM000377	Bushing				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150350	Plug				
2	4	L66150323	Screw				
3	1	L66150476	Gasket				
4	1	L66150477	Tube				
5	1	3055123	Spark plug				
6	1	L66150276	Gasket				
7	1	L66150309	Gasket				
8	1	L66150599	Gasket set				
9	1	L66150598	Head comp.cylinder				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150478	Seal ring				
2	1	L66150355	Bearing				
3	1	L66150302	Shaft				
4	1	L66150353	Plug				
5	1	L66150479	Governor				
6	1	L66150480	Cable				
7	2	L66150354	Washer				
8	2	L66150352	Screw				
9	1	L66150325	Washer				
10	1	L66150599	Gasket set				
11	1	L66150698	Extension hose			Corto; Short	




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150271	Cap				
2	1	L66150481	Seal ring				
3	1	L66150355	Bearing				
4	1	L66150274	Gasket				
5	6	L66150319	Screw				
6	1	L66150273	Crankcase cover				
7	2	L66150357	Plug				
8	1	L66150599	Gasket set				





Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150280	Piston ring set				
2	1	L66150600	Piston assy				
3	1	L66150281	Connecting rod cpl.				
4	1	L66150482	Shaft				
5	2	L66150372	Retainer washer				
6	1	L66150081	Key				
7	1	L66150483	Key				
8	1	L66150342	Piston pin				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150368	Compensator				
2	1	L66150287	Plate (guide)				
3	2	L66150285	Rod				
4	2	L66150286	Slide				
5	2	L66150364	Valve				
6	2	L66150365	Ring				
7	2	L66150366	Valves spring				
8	1	L66150484	Slide				
9	1	L66150362	Reed valve kit				
10	1	L66150363	Complete shaft				
11	1	L66150598	Head comp.cylinder				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150485	Starter assy				
2	1	L66150330	Fixing screw				
3	1	L66150331	Clutch driver				
4	1	L66150332	Spring				
5	2	L66150263	Pawl				
6	2	L66150264	Spring				
7	1	L66150265	Pulley				
8	1	L66150336	Starter spring				
9	1	L66150486	Handle				
10	1	L66150487	Starter rope				
11	4	L66150322	Screw				
12	1	L66150488	Starter assy				
13	2	L66150339	Screw				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150291	Gasket				
2	1	L66150293	Insulator				
3	1	L66150290	Gasket				
4	1	L66150489	Carburetor		05/13		BT6-093-12/13
5	1	L66150292	Gasket				
6	1	L66150697	Air lever	06/13			BT6-093-12/13
7	1	L66150702	Primer pump				
8	1	L66150701	Carburetor	06/13			BT6-093-12/13




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150490	Ignition coil				
2	1	L66150491	Spark plug cap				
3	2	L66150321	Screw				
4	1	L66150313	Flywheel				
5	1	L66150288	Fan				
6	1	L66150312	Pulley				
7	1	L66150376	Nut				
8	1	L66150492	Case				
9	1	L66150493	Switch				




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150495	Throttle rod				
2	1	L66150300	Spring				
3	1	L66150382	Screw				
4	1	L66150185	Nut				
5	1	L66150496	Spring				
6	1	L66150240	Screw				
7	1	L66150497	Switch (stop)				
8	1	L66150380	Spring				
9	1	L66150381	Screw				
10	1	L66150498	Complete lever				
11	1	L66150499	Rubber protection				


I° Serie / Ist Serie




II° Serie / IInd Series




Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150500	Elbow		05/13		BT6-093-12/13
2	1	L66150501	Air filter kit		05/13		BT6-093-12/13
3	1	L66150502	Starter lever		05/13		BT6-093-12/13
4	1	L66150505	Clip		05/13		BT6-093-12/13
5	1	L66150504	Knob		05/13		BT6-093-12/13
6	1	L66150705	Air filter	06/13			BT6-093-12/13



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150506	Complete muffler				
2	2	L66150348	Nut				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150507	Knob				
2	1	L66150508	Switch				
3	3	L66150185	Nut				
4	2	L66150509	Clip				
5	1	L66150510	Tube				
6	1	L66150295	Fitting				
7	4	L66150322	Screw				
8	1	L66150601	Complete tank				
9	1	L66150511	Cap				
10	1	L66150515	Tube				
11	1	L66150512	Cover				
12	1	L66150513	Complete cap				
13	1	L66150514	Filter				



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150516	Guard				
2	1	L66150517	Guard				