


# DS 3800 T - Engine




## DS 3800 T - Engine



| Ref.Nu | Qty | Part number | Description                  | Validity from       | Validity till   | Notes | Bulletin              |
|--------|-----|-------------|------------------------------|---------------------|-----------------|-------|-----------------------|
| 1      | 1   | 2318817R    | Air purge                    |                     |                 |       |                       |
| 2      | 1   | 61250118AR  | Muffler cover                |                     |                 |       |                       |
| 3      | 2   | 4191069B    | Plate                        |                     | matr.2250193407 |       | BT3-<br>102-<br>01/11 |
| 4      | 2   | 3801069R    | Screw                        |                     |                 |       |                       |
| 5      | 2   | 3819036R    | Washer                       |                     |                 |       |                       |
| 6      | 2   | 3916006     | Washer                       |                     |                 |       |                       |
| 7      | 1   | 61250192AR  | Compl. muffler<br>KAT EURO 2 |                     |                 |       |                       |
| 8      | 1   | 61210035R   | Deflector                    |                     |                 |       |                       |
| 9      | 1   | 3055115     | Spark plug                   |                     |                 |       |                       |
| 10     | 1   | 61200007AR  | Gasket                       |                     |                 |       |                       |
| 11     | 2   | 003300015R  | Piston ring                  |                     |                 |       | BT3-<br>114-<br>05/12 |
| 12     | 2   | 004900061R  | Ring                         |                     |                 |       | BT3-<br>114-<br>05/12 |
| 13     | 1   | 50110047R   | Piston pin                   |                     |                 |       | BT3-<br>114-<br>05/12 |
| 14     | 1   | 61212004A   | Piston assy Ø38              | matr.<br>2252100347 |                 |       | BT3-<br>114-<br>05/12 |
| 15     | 1   | 61212005A   | Compl. cylinder              | matr.<br>2252100347 |                 |       | BT3-<br>114-<br>05/12 |
| 16     | 1   | 50110044R   | Bearing                      |                     |                 |       |                       |
| 17     | 2   | 50110043R   | Spacer                       |                     |                 |       |                       |
| 18     | 1   | 61200001R   | Crankshaft                   |                     |                 |       |                       |
| 19     | 1   | 61250250    | Stopper                      |                     |                 |       | BT3-<br>089-<br>03/10 |
| 20     | 1   | 61200113AR  | Crankcase assy               |                     |                 |       |                       |
| 21     | 4   | 3860096     | Screw                        |                     |                 |       |                       |
| 22     | 2   | 094000006R  | Bearing                      |                     |                 |       |                       |
| 23     | 1   | 61200006R   | Gasket                       |                     |                 |       |                       |
| 24     | 2   | 094000099R  | Seal ring                    |                     |                 |       |                       |
| 25     | 4   | 094000101R  | Screw                        |                     |                 |       |                       |
| 26     | 4   | 3833073R    | Washer                       |                     |                 |       |                       |
| 27     | 2   | 3023008R    | Plug                         |                     |                 |       |                       |
| 28     | 1   | 3916005R    | Sealing washer               |                     |                 |       |                       |
| 29     | 1   | 3819006R    | Washer                       |                     |                 |       |                       |
| 30     | 1   | 3801010R    | Screw                        |                     |                 |       |                       |
| 31     | 2   | 3960030     | Screw                        |                     | matr.2250193407 |       | BT3-                  |

| Ref.Nu | Qty | Part number | Description    | Validity from | Validity till | Notes | Bulletin      |
|--------|-----|-------------|----------------|---------------|---------------|-------|---------------|
| 32     | 3   | 3960087AR   | Screw          |               |               |       | 102-01/11     |
| 33     | 1   | 61250251R   | Cylinder cover |               |               |       | BT3-089-03/10 |
| 34     | 1   | 61250046R   | Plug cap       |               |               |       |               |
| 35     | 4   | 3960070AR   | Screw          |               |               |       |               |
| 36     | 1   | 61202038R   | Gasket set     |               |               |       |               |
| 37     | 1   | 61250249R   | Adjust. pin    |               |               |       | BT3-089-03/10 |
| 38     | 1   | 61252075R   | Short block    |               |               |       |               |

DS 3800 T - Starter assy and clutch






## DS 3800 T - Starter assy and clutch



| Ref.Nu | Qty | Part number | Description    | Validity from   | Validity till   | Notes  | Bulletin      |
|--------|-----|-------------|----------------|-----------------|-----------------|--------|---------------|
| 1      | 1   | 61250203R   | Starter assy   |                 |                 |        |               |
| 2      | 1   | 61200015R   | Starter handle |                 |                 |        |               |
| 3      | 1   | 4098073R    | Starter rope   |                 |                 |        |               |
| 4      | 8   | 3916006     | Washer         |                 |                 |        |               |
| 5      | 8   | 3916005R    | Sealing washer |                 |                 |        |               |
| 6      | 1   | 004000132R  | Spring         |                 |                 |        |               |
| 7      | 1   | 4191018BR   | Starter pulley |                 |                 |        |               |
| 8      | 2   | 3024007     | Ring           |                 |                 |        |               |
| 9      | 1   | 61250056R   | Flange         |                 |                 |        |               |
| 10     | 2   | 4191017A    | Spring         |                 |                 |        |               |
| 11     | 3   | 3918006     | Washer         |                 |                 |        |               |
| 12     | 1   | 61200012R   | Spark plug cap |                 | matr.2251077045 | Ø 7 mm | BT3-105-04/11 |
| 13     | 1   | 61252002R   | Clutch driver  |                 |                 |        |               |
| 14     | 1   | 61250197AR  | Ignition coil  | matr.2251077046 |                 |        | BT3-105-04/11 |
| 15     | 1   | 61250282R   | Cable          | matr.2250193408 |                 |        | BT3-102-01/11 |
| 15     | 1   | 61250047R   | Cable          |                 | matr.2250193407 |        | BT3-102-01/11 |
| 16     | 8   | 3801013R    | Screw          |                 |                 |        |               |
| 17     | 1   | 4196038     | Bushing        |                 |                 |        |               |
| 18     | 1   | 3912009     | Nut            |                 |                 |        |               |
| 19     | 1   | 3818011A    | Washer         |                 |                 |        |               |
| 20     | 1   | 61250014AR  | Flywheel       |                 |                 |        |               |
| 21     | 1   | 61250019R   | Clamp          |                 |                 |        |               |
| 22     | 2   | 3801016R    | Screw          |                 |                 |        |               |
| 23     | 1   | 61250020R   | Clamp          |                 |                 |        |               |
| 24     | 1   | 3914003R    | Nut            |                 |                 |        |               |
| 25     | 2   | 4191016     | Pawl           |                 |                 |        |               |
| 26     | 1   | 61250023R   | Sleeve         |                 |                 |        |               |
| 27     | 1   | 3024015     | Seeger         |                 |                 |        |               |
| 28     | 1   | 61250017AR  | Starter case   |                 |                 |        |               |
| 29     | 1   | 3035015R    | Bearing        |                 |                 |        |               |
| 30     | 1   | 3025022R    | Seeger         |                 |                 |        |               |
| 31     | 1   | 61250105AR  | Clutch drum    |                 |                 |        | BT3-093-05/10 |
| 32     | 2   | 4191027FR   | Pin            |                 |                 |        |               |
| 33     | 1   | 4191028R    | Spring         |                 |                 |        |               |
| 34     | 1   | 4191153AR   | Clutch         |                 |                 |        |               |

| Ref.Nu | Qty | Part number | Description    | Validity from   | Validity till | Notes  | Bulletin              |
|--------|-----|-------------|----------------|-----------------|---------------|--------|-----------------------|
| 35     | 1   | 61200067R   | Spring         |                 |               |        |                       |
| 36     | 2   | 3960099R    | Screw          |                 |               |        |                       |
| 37     | 1   | 61250104R   | Clutch drum    |                 |               |        | BT3-<br>093-<br>05/10 |
| 38     | 1   | 61250106R   | Bushing        |                 |               |        |                       |
| 39     | 1   | 61250022R   | Clamp          |                 |               |        |                       |
| 40     | 1   | 61250021R   | Clamp          |                 |               |        |                       |
| 41     | 1   | 50050126    | Spark plug cap | matr.2251077046 |               | Ø 5 mm | BT3-<br>105-<br>04/11 |

# DS 3800 T - Fuel tank and air filter






## DS 3800 T - Fuel tank and air filter



| Ref.Nu | Qty | Part number | Description        | Validity from     | Validity till | Notes | Bulletin      |
|--------|-----|-------------|--------------------|-------------------|---------------|-------|---------------|
| 1      | 1   | 61200019AR  | Gasket             |                   |               |       |               |
| 2      | 1   | 61200198    | Insulator          |                   |               |       |               |
| 3      | 1   | 3801015     | Screw              |                   |               |       |               |
| 4      | 1   | 61250075R   | Support            |                   |               |       |               |
| 5      | 1   | 61200196R   | Gasket             |                   |               |       |               |
| 6      | 1   | 2318735CR   | Carburetor WT-870C |                   |               |       | BT3-089-03/10 |
| 7      | 1   | 61170016R   | Air filter         |                   |               |       |               |
| 8      | 1   | 61250207R   | Filter cover       |                   |               |       |               |
| 9      | 1   | 61250076R   | Tank               |                   |               |       |               |
| 10     | 1   | 4098377     | Band               |                   |               |       |               |
| 11     | 2   | 61070078    | Hose               |                   |               |       |               |
| 12     | 1   | 61170131    | Hose               |                   |               |       |               |
| 13     | 1   | 4161211     | Bush               |                   |               |       |               |
| 14     | 1   | 61070011AR  | Breather valve     |                   |               |       |               |
| 15     | 1   | 61200030AR  | Hose               |                   |               |       |               |
| 16     | 1   | 61252040R   | Complete cap       |                   |               |       |               |
| 17     | 1   | 61070006    | Gasket             |                   |               |       |               |
| 18     | 1   | 094600450R  | Fuel filter        |                   |               |       |               |
| 19     | 1   | 61250035AR  | Stand              | s.n<br>2259433747 |               |       | BT3-087-02/10 |
| 20     | 5   | 3819006R    | Washer             |                   |               |       |               |
| 21     | 5   | 3918005     | Washer             |                   |               |       |               |
| 22     | 1   | 3801013R    | Screw              |                   |               |       |               |
| 23     | 2   | 4175082     | Screw              |                   |               |       |               |
| 24     | 1   | 61250027R   | Lever              |                   |               |       |               |
| 25     | 1   | 3960087     | Screw              |                   |               |       |               |
| 26     | 1   | 61250028BR  | Shutter            |                   |               |       |               |
| 27     | 1   | 3916004R    | Washer             |                   |               |       |               |
| 28     | 4   | 61200128R   | Insert             |                   |               |       |               |
| 29     | 4   | 3916008R    | Washer             |                   |               |       |               |
| 30     | 4   | 61200129R   | Spring             |                   |               |       |               |
| 31     | 4   | 3801016R    | Screw              |                   |               |       |               |
| 32     | 1   | 61250026R   | Guard              |                   |               |       |               |
| 33     | 1   | 61250257    | Hose               |                   |               |       | BT3-089-03/10 |
| 34     | 1   | 61202038R   | Gasket set         |                   |               |       |               |



DS 3800 T - Transmission Ø26



## DS 3800 T - Transmission Ø26






| Ref.Nu | Qty | Part number | Description     | Validity from | Validity till       | Notes | Bulletin  |
|--------|-----|-------------|-----------------|---------------|---------------------|-------|---|
| 1      | 1   | 61252029R   | Compl. suupport |               |                     |       | BT3-<br>093-<br>05/10                           |
| 2      | 1   | 61252043    | Compl. case     |               |                     |       |   |
| 3      | 1   | 61170095    | Spring          |               |                     |       |   |
| 4      | 4   | 61030012R   | Clamp           |               |                     |       | BT3-<br>093-<br>05/10                           |
| 5      | 5   | 3914003R    | Nut             |               |                     |       | BT3-<br>092-<br>03/10,<br>BT3-<br>113-<br>03/12 |
| 6      | 1   | 61170094    | Slide control   |               |                     |       |   |
| 7      | 1   | 61250181R   | Sleeve          |               |                     |       |   |
| 8      | 1   | 61250180R   | Plate           |               |                     |       |   |
| 9      | 1   | 3980011     | Nut             |               |                     |       |   |
| 10     | 1   | 66030012    | Washer          |               |                     |       |   |
| 11     | 2   | 3801016R    | Screw           |               | matr.<br>2252100346 |       | BT3-<br>092-<br>03/10,<br>BT3-<br>113-<br>03/12 |
| 12     | 1   | 61040155    | Compl. clamp    |               | matr.<br>2252100346 |       | BT3-<br>092-<br>03/10,<br>BT3-<br>113-<br>03/12 |
| 13     | 1   | 61040044    | Spring          |               |                     |       | BT3-<br>092-<br>03/10                           |
| 14     | 1   | 3918013     | Washer          |               |                     |       | BT3-<br>092-<br>03/10                           |
| 15     | 1   | 61042030    | Knob            |               |                     |       | BT3-<br>092-<br>03/10                           |
| 16     | 1   | 61202023R   | Tube Ø26        |               |                     |       | BT3-<br>093-<br>05/10                           |
| 17     | 1   | 61170075R   | Drive shaft     |               |                     |       | BT3-<br>093-<br>05/10                           |
| 18     | 1   | 61040140R   | Knob            |               | matr.<br>2252100346 |       | BT3-<br>113-<br>03/12                           |

| Ref.Nu | Qty | Part number | Description    | Validity from   | Validity till       | Notes | Bulletin  |
|--------|-----|-------------|----------------|-----------------|---------------------|-------|---|
| 19     | 1   | 61172043    | Handle kit     |                 | matr.<br>2252100346 |       | BT3-<br>113-<br>03/12                           |
| 20     | 1   | 3960067AR   | Screw          |                 |                     |       |   |
| 21     | 1   | 61170093    | Plate          |                 |                     |       |   |
| 22     | 1   | 61170091    | Throttle lever |                 |                     |       |   |
| 23     | 1   | 61170092    | Lever          |                 |                     |       |   |
| 24     | 1   | 61170096    | Spring         |                 |                     |       |   |
| 25     | 1   | 61280067AR  | Throttle cable |                 | matr.<br>2252100346 |       | BT3-<br>089-<br>03/10,<br>BT3-<br>113-<br>03/12 |
| 26     | 1   | 61280124R   | Cable          | matr.2250193408 | matr.<br>2252100346 |       | BT3-<br>102-<br>01/11,<br>BT3-<br>113-<br>03/12 |
| 26     | 1   | 61250166R   | Cable          |                 | matr.2250193407     |       | BT3-<br>102-<br>01/11                           |
| 27     | 1   | 61072037R   | Handlebar      |                 | matr.<br>2252100346 |       | BT3-<br>113-<br>03/12                           |
| 28     | 1   | 61170113    | Plate          |                 |                     |       |   |
| 30     | 1   | 3960021     | Screw          |                 |                     |       |   |
| 31     | 1   | 61280128    | Compl. handle  |                 | matr.<br>2252100346 |       | BT3-<br>113-<br>03/12                           |
| 32     | 1   | 61040074AR  | Screw          |                 |                     |       |   |
| 33     | 1   | 4100456R    | Guard          |                 |                     |       |   |
| 34     | 1   | 4179089R    | Flange         |                 |                     |       |   |
| 35     | 1   | 3025019     | Ring           |                 |                     |       |   |
| 36     | 1   | 3024012     | Ring           |                 |                     |       |   |
| 37     | 2   | 3034008     | Bearing        |                 |                     |       |   |
| 38     | 1   | 61252045    | Compl. cover   |                 |                     |       |   |
| 39     | 1   | 3025009     | Ring           |                 |                     |       |   |
| 40     | 1   | 4138311A    | Ring           |                 |                     |       |   |
| 41     | 1   | 61040144R   | Gear case      |                 |                     |       |   |
| 42     | 1   | 61040071R   | Cap            |                 |                     |       |   |
| 43     | 1   | 3901016     | Screw          |                 |                     |       |   |
| 44     | 1   | 3034218     | Bearing        |                 |                     |       |   |
| 45     | 1   | 61040106A   | Pin            |                 |                     |       |   |
| 46     | 1   | 3034012R    | Bearing        |                 |                     |       |   |
| 47     | 1   | 3025022R    | Seeger         |                 |                     |       |   |
| 48     | 1   | 3050018R    | Seal ring      |                 |                     |       |   |
| 49     | 1   | 61040066R   | Spacer         |                 |                     |       |   |
| 50     | 1   | 61040145R   | Hub            |                 |                     |       |   |
| 51     | 1   | 61052030BR  | Bevel gear Ø26 |                 |                     |       |   |
| 52     | 1   | 61040132    | Gear set       |                 |                     |       |   |

| Ref.Nu | Qty | Part number | Description                    | Validity from       | Validity till | Notes | Bulletin              |
|--------|-----|-------------|--------------------------------|---------------------|---------------|-------|-----------------------|
| 53     | 1   | 3901008R    | Screw                          |                     |               |       |                       |
| 54     | 1   | 61250237    | Set bevel gear<br>Ø26 + Insert |                     |               |       | BT3-<br>093-<br>05/10 |
| 55     | 1   | 61250054R   | Pin                            |                     |               |       |                       |
| 56     | 1   | 61110074R   | Guard                          |                     |               |       |                       |
| 57     | 1   | 61110075R   | Nut                            |                     |               |       |                       |
| 58     | 1   | 61250299    | Compl. handle                  | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |
| 59     | 1   | 61250297    | Clamp cpl.                     | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |
| 60     | 1   | 61250298    | Half handle kit                | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |
| 61     | 1   | 61350018R   | Handle                         | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |
| 62     | 1   | 61250296R   | Handle                         | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |
| 63     | 1   | 61250306R   | Throttle cable                 | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |
| 64     | 1   | 61250307R   | Cable                          | matr.<br>2252100347 |               |       | BT3-<br>113-<br>03/12 |

DS 3800 T - Transmission Ø28



## DS 3800 T - Transmission Ø28




| Ref.Nu | Qty | Part number | Description     | Validity from | Validity till       | Notes | Bulletin                        |
|--------|-----|-------------|-----------------|---------------|---------------------|-------|---------------------------------|
| 1      | Ø28 | 61252027R   | Compl. suupport |               |                     |       | BT3-093-05/10                   |
| 2      | 1   | 61252043    | Compl. case     |               |                     |       |                                 |
| 3      | 1   | 61170095    | Spring          |               |                     |       |                                 |
| 4      | 4   | 61040110R   | Clamp           |               |                     |       | BT3-093-05/10                   |
| 5      | 5   | 3914003R    | Nut             |               |                     |       | BT3-092-03/10,<br>BT3-113-03/12 |
| 6      | 1   | 61170094    | Slide control   |               |                     |       |                                 |
| 7      | 1   | 61250181R   | Sleeve          |               |                     |       |                                 |
| 8      | 1   | 61250180R   | Plate           |               |                     |       |                                 |
| 9      | 1   | 3980011     | Nut             |               |                     |       |                                 |
| 10     | 1   | 66030012    | Washer          |               |                     |       |                                 |
| 11     | 2   | 3801016R    | Screw           |               | matr.<br>2252100346 |       | BT3-092-03/10,<br>BT3-113-03/12 |
| 12     | 1   | 61040155    | Compl. clamp    |               | matr.<br>2252100346 |       | BT3-092-03/10,<br>BT3-113-03/12 |
| 13     | 1   | 61040044    | Spring          |               |                     |       | BT3-092-03/10                   |
| 14     | 1   | 3918013     | Washer          |               |                     |       | BT3-092-03/10                   |
| 15     | 1   | 61042030    | Knob            |               |                     |       | BT3-092-03/10                   |
| 16     | 1   | 61252049R   | Tube Ø28        |               |                     |       | BT3-093-05/10                   |
| 17     | 1   | 61200187R   | Drive shaft     |               |                     |       | BT3-093-05/10                   |
| 18     | 1   | 61040140R   | Knob            |               | matr.<br>2252100346 |       | BT3-113-03/12                   |
| 19     | 1   | 61172043    | Handle kit      |               | matr.<br>2252100346 |       | BT3-113-03/12                   |
| 20     | 1   | 3960067AR   | Screw           |               |                     |       |                                 |
| 21     | 1   | 61170093    | Plate           |               |                     |       |                                 |
| 22     | 1   | 61170091    | Throttle lever  |               |                     |       |                                 |
| 23     | 1   | 61170092    | Lever           |               |                     |       |                                 |
| 24     | 1   | 61170096    | Spring          |               |                     |       |                                 |
| 25     | 1   | 61280067AR  | Throttle cable  |               | matr.<br>2252100346 |       | BT3-089-03/10,<br>BT3-113-03/12 |
| 26     | 1   | 61280124R   | Cable           |               | matr.               |       | BT3-113-                        |

| Ref.Nu | Qty | Part number | Description     | Validity from       | Validity till       | Notes | Bulletin          |
|--------|-----|-------------|-----------------|---------------------|---------------------|-------|-------------------|
|        |     |             |                 |                     | 2252100346          |       | 03/12             |
| 27     | 1   | 61072037R   | Handlebar       |                     | matr.<br>2252100346 |       | BT3-113-<br>03/12 |
| 28     | 1   | 61170113    | Plate           |                     |                     |       |                   |
| 30     | 1   | 3960021     | Screw           |                     |                     |       |                   |
| 31     | 1   | 61280128    | Compl. handle   |                     | matr.<br>2252100346 |       | BT3-113-<br>03/12 |
| 32     | 1   | 61110075R   | Nut             |                     |                     |       |                   |
| 33     | 1   | 61110074R   | Guard           |                     |                     |       |                   |
| 34     | 1   | 4179089R    | Flange          |                     |                     |       |                   |
| 35     | 1   | 3025019     | Ring            |                     |                     |       |                   |
| 36     | 1   | 3024010R    | Ring            |                     |                     |       |                   |
| 37     | 2   | 3035040R    | Bearing         |                     |                     |       |                   |
| 38     | 1   | 61252045    | Compl. cover    |                     |                     |       |                   |
| 39     | 1   | 3025009     | Ring            |                     |                     |       |                   |
| 40     | 1   | 4138311A    | Ring            |                     |                     |       |                   |
| 41     | 1   | 61040144R   | Gear case       |                     |                     |       |                   |
| 42     | 1   | 61040071R   | Cap             |                     |                     |       |                   |
| 43     | 1   | 3901016     | Screw           |                     |                     |       |                   |
| 44     | 1   | 3034218     | Bearing         |                     |                     |       |                   |
| 45     | 1   | 61250054R   | Pin             |                     |                     |       |                   |
| 46     | 1   | 3034012R    | Bearing         |                     |                     |       |                   |
| 47     | 1   | 3025022R    | Seeger          |                     |                     |       |                   |
| 48     | 1   | 3050018R    | Seal ring       |                     |                     |       |                   |
| 49     | 1   | 61040066R   | Spacer          |                     |                     |       |                   |
| 50     | 1   | 61040145R   | Hub             |                     |                     |       |                   |
| 51     | 1   | 61250066R   | Bevel gear Ø28  |                     |                     |       | BT3-093-<br>05/10 |
| 52     | 1   | 61040133    | Bevel gear set  |                     |                     |       |                   |
| 53     | 1   | 3901008R    | Screw           |                     |                     |       |                   |
| 54     | 1   | 61250298    | Half handle kit | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |
| 55     | 1   | 61250306R   | Throttle cable  | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |
| 56     | 1   | 61350018R   | Handle          | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |
| 57     | 1   | 61250296R   | Handle          | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |
| 58     | 1   | 61250299    | Compl. handle   | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |
| 59     | 1   | 61250297    | Clamp cpl.      | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |
| 60     | 1   | 61250307R   | Cable           | matr.<br>2252100347 |                     |       | BT3-113-<br>03/12 |

# DS 3800 T - Carburatore WT-870



## Walbro WT-870B



15 ■ KIT RIPARAZIONE  
REPAIR KIT











## DS 3800 T - Carburetor WT-870



| Ref.Nu | Qty | Part number | Description   | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|---------------|---------------|---------------|-------|----------|
| 1      | 1   | 50010141    | Screw         |               |               |       |          |
| 2      | 2   | 095000164   | Ring          |               |               |       |          |
| 3      | 1   | 095000141   | Shutter       |               |               |       |          |
| 4      | 1   | 2318211     | Pin           |               |               |       |          |
| 5      | 1   | 2318786     | Shaft         |               |               |       |          |
| 6      | 1   | 094600208   | Spring        |               |               |       |          |
| 7      | 1   | 2318736     | Adjust. screw |               |               |       |          |
| 8      | 2   | 2318687     | Caps-lock     |               |               |       |          |
| 9      | 1   | 2318631     | Adjust. screw |               |               |       |          |
| 10     | 1   | 2318191     | Cover         |               |               |       |          |
| 11     | 4   | 035000162   | Screw         |               |               |       |          |
| 12     | 1   | 003300197   | Screw         |               |               |       |          |
| 13     | 1   | 50050107    | Cover         |               |               |       |          |
| 14     | 1   | 003300201   | Spindle       |               |               |       |          |
| 15     | 1   | 2318671     | Repair kit    |               |               |       |          |
| 16     | 1   | 074000240   | Adjust.screw  |               |               |       |          |
| 17     | 1   | 094600148   | Spring        |               |               |       |          |
| 18     | 1   | 2318607     | Spring        |               |               |       |          |

# DS 3800 T - Accessories



## DS 3800 T - Accessories



| Ref.Nu | Qty | Part number | Description                 | Validity from | Validity till | Notes | Bulletin |
|--------|-----|-------------|-----------------------------|---------------|---------------|-------|----------|
| 1      | 1   | 63019018    | Compl. nylon head<br>Ø3     |               |               |       |          |
| 2      | 2   | 3960040R    | Screw                       |               |               |       |          |
| 3      | 1   | 4174278     | Plate                       |               |               |       |          |
| 4      | 4   | 3802004CR   | Screw                       |               |               |       |          |
| 5      | 1   | 4179113A    | Skirt w/blade               |               |               |       |          |
| 6      | 1   | 4174275R    | Blade                       |               |               |       |          |
| 7      | 1   | 61042035A   | Guard                       |               |               |       |          |
| 8      | 2   | 4199005A    | Bushing                     |               |               |       |          |
| 9      | 1   | 61110076    | Insert                      |               |               |       |          |
| 10     | 1   | 4199004     | Spring                      |               |               |       |          |
| 11     | 1   | 4199031A    | Nylon spool Ø3              |               |               |       |          |
| 12     | 1   | 4095673AR   | Disk                        |               |               |       |          |
| 13     | 1   | 4199035AR   | Cover                       |               |               |       |          |
| 14     | 1   | 61052031    | Tool kit                    |               |               |       |          |
| 15     | 1   | 63050018AR  | Harness                     |               |               |       |          |
| 16     | 1   | 63050016    | Hooking spring              |               |               |       |          |
| 17     | 1   | 4199039AR   | Compl. nylon head<br>Ø3     |               |               |       |          |
| 18     | 1   | 4199008B    | Insert                      |               |               |       |          |
| 19     | 1   | 63019010A   | Quick load nylon<br>head Ø3 |               |               |       |          |
| 20     | 1   | 4199048R    | Spring                      |               |               |       |          |
| 21     | 1   | 4199049     | Nylon spool                 |               |               |       |          |
| 22     | 1   | 4199046     | Cover                       |               |               |       |          |
| 23     | 1   | 63019012A   | Quick load nylon<br>head Ø3 |               |               |       |          |
| 24     | 1   | 4199042R    | Nylon+spool Ø3              |               |               |       |          |