




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

LB553 Se, 967257001, 2014

C LB553S e
ENGINE




ENGINE

LB553 Se, 967257001, 2014


Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	732 21 18-01	LOCK NUT		3	
2	734 11 64-01	Шайба		6	
3	.	TBD	GCV 160 A0 A3-HV-SD	1	
5	725 24 63-51	SCREW EHHM		3	
6	295 67 30-02	Ремень приводной 272К 14"	Kit: 580 86 28-01 (Belt with shell)	1	
7	505 39 03-01	SCREW IHSETM		2	
8	577 61 11-01	Шкив		1	
9	295 68 82-01	BLADE SUPPORT		1	15
10	295 67 32-10	MOWER BLADE	Kit: 531 00 92-54 (Blade with box)	1	
11	295 67 44-01	Пружина		1	15
12	295 68 85-01	Шайба		1	15
13	295 67 46-02	BOLT 0 16X32		1	
14	585 83 52-05	Наклейка		1	
15	531 00 92-73	ADAPTER		1	

B LB553S e
HANDLE



Спр. №	Код	Описание	Замечание	КОЛ Наб.
28	725 23 82-51	SCREW EHHM		1
1	503 31 11-02	BAIL ARM ASSY		1
2	576 64 19-01	HANDLE GRIP		1
3	503 32 09-01	BUSHING		1
4	734 18 20-51	Шайба		1
5	725 23 81-51	SCREW EHHM		2
6	504 45 99-01	Шайба		1
7	732 25 16-01	HEXAGON LOCKING NUT		2
8	585 40 21-01	Провод		1
9	502 90 64-03	Рукоятка и тросик		1
10	579 20 35-01	THROTTLE CONTROL		1
11	579 20 34-01	DRIVE CONTROL		1
12	504 46 15-01	SCREW CRPANM		4
13	503 31 17-02	Пластина		1
14	502 90 35-02	Рукоятка и тросик		1
15	731 23 18-01	HEXAGON NUT		4
16	735 21 64-01	WASHER		4
17	503 31 25-02	ANTI-VIBRATION MOUNT		4
18	503 29 83-02	LEVER ASSY		1
19	504 45 73-01	Шайба		1
20	727 65 43-51	SCREW RSQM		1 21
21	578 78 99-01	Рукоятка и тросик		1
22	295 68 05-01	Шайба		2
23	727 64 57-51	SCREW RSQM		2
24	579 41 39-01	ADJUSTMENT ROD		1
25	579 29 71-01	Пружина		2
26	732 21 18-01	LOCK NUT		2
27	531 20 49-61	Шайба		2
28	725 23 82-51	SCREW EHHM		1

A LB553S e
DECK



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	295 67 71-05	Гайка		4	
2	295 66 67-02	Шайба		4	
3	295 66 71-04	Колесо		2	
4	295 67 42-01	Съемник подшипника	6201 2RS/C3	10	3, 52
5	295 68 87-04	WHEEL		2	3
6	295 66 72-01	Втулка		4	3, 52
7	295 68 04-03	LOCKING NUT		10	
8	295 66 62-02	Втулка		2	
9	295 67 52-01	SPACER WASHER		2	
10	295 66 73-01	GUARD, R.H.		2	
11	579 58 06-01	GUARD, R.H.		2	
12	729 57 74-01	SCREW CRPANT		6	
13	295 67 74-01	Резиновое кольцо		4	
14	740 42 10-00	Сальник		4	
16	727 63 72-51	SCREW		10	
17	295 67 43-01	Пружина		1	
18	295 67 81-01	BALL		1	
19	578 79 02-01	HANDLE SUPPORT ASSY		1	
20	579 58 17-01	LINK ARM		1	
21	295 66 16-02	LEVER ASSY		1	
22	725 63 78-51	SCREW IHCSFM		1	
23	734 11 56-01	Шайба		1	
24	731 71 16-51	HEXAGON NUT FLANGE		1	
25	725 23 68-01	SCREW		2	
26	523 06 61-01	Шайба		2	
27	295 66 77-01	Привод дросселя		1	
28	295 66 09-01	AXLE		1	
29	295 65 90-01	Крышка в сборе		1	
30	295 66 03-01	ROD		2	
31	578 33 87-01	DISC SPRING		2	
32	579 58 11-01	AXLE		1	
33	295 67 87-02	Пружина		2	
34	735 31 14-01	Шайба		4	
35	295 66 69-01	PINION		2	
36	578 79 01-01	HANDLE SUPPORT ASSY		1	
37	295 65 96-01	Тяга		2	
38	579 58 10-01	Тяга		2	
40	295 66 17-01	HOLDER		2	
41	578 97 60-02	SCREW ITXPANTT		5	
42	577 51 12-01	КРЫШКА		1	
44	729 53 40-01	SCREW CCRPANT		1	
45	579 58 08-01	GEARBOX		1	
46	295 67 89-01	Кронштейн		1	
47	295 67 48-01	Пружина		1	
48	502 43 52-01	SCREW ITXPANTT		2	
49	295 66 74-01	Патрубок глушителя 2094		1	
50	579 73 39-01	Наклейка		1	
51	520 29 05-02	Наклейка		1	
52	295 66 70-04	WHEEL		2	
53	295 68 86-04	WHEEL		2	52
54	586 58 85-01	Заглушка	For chassis with hole	1	