




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS

LC140 S, 967320101, 2014-01



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	587 91 38-01	LOCKING BOLT		1
2	587 91 07-01	Шайба		1
3	587 38 63-10	MOWER BLADE		1
4	587 91 12-01	BLADE SUPPORT		1
5	587 91 54-01	BUSH		1
6	587 91 53-01	Плоский контакт		1
7	587 91 28-01	SCREW		1
8	587 91 20-01	Шкив		1
9	587 90 96-01	Ремень приводной 272К 14"		1
10	587 91 22-01	SCREW		2
11	587 91 26-01	SCREW		7
12	587 90 98-01	КРЫШКА		1
13	587 91 34-01	LOCK NUT		9
14	587 58 50-01	WHEEL COVER		2
15	587 58 52-01	WHEEL COVER		2
16	587 91 35-01	LOCKING BOLT		11
17	587 91 29-01	Игольчатый подшипник		8
18	587 58 54-01	Колесо		2
19	587 91 46-01	Шайба		4
20	587 91 25-01	SCREW		4
21	587 91 10-01	FIXING PLATE		2
22	587 91 15-01	AXLE		1
23	587 91 47-01	Шайба		4
24	587 91 57-01	Редуктор 322 325		1
25	587 91 45-01	Шайба		2
26	587 91 30-01	Игольчатый подшипник		2
27	587 91 55-01	Корпус подшипника		2
28	587 91 52-01	Гаечка 250PS		2
29	587 90 87-01	GEARBOX ASSY		1
30	587 91 02-01	BUSHING		1
31	587 91 56-01	Редуктор 322 325		1
32	587 91 09-01	FIXING PLATE		2
33	587 91 24-01	SCREW		2
34	587 58 49-01	FRONT COVER		1
35	587 90 97-01	LOCKING RING		2
36	587 58 51-01	WHEEL COVER		2
37	587 58 53-01	WHEEL COVER		2
38	587 58 55-01	Колесо		2
39	587 91 01-01	Набор шестернь		2
40	587 91 21-01	SCREW		14
41	587 58 62-01	КРЫШКА		2
42	587 91 48-01	Шайба		2
43	587 91 16-01	AXLE		1
44	587 91 08-01	Шайба		1
45	587 90 99-01	SEGMENT		1
46	587 90 88-01	Пластина		1
47	587 91 27-01	Шайба		1
48	587 91 19-01	Рукоятка и тросик		1
49	587 58 57-01	KNOB		1
50	587 91 00-01	КРЫШКА		1
51	587 91 13-01	PLATE		1
52	587 91 41-01	BOLT 0 16X32		2
53	587 91 31-01	LOCKING BOLT		3
54	587 91 58-01	TUBING		2
55	587 91 49-01	Пружина		1
56	587 91 17-01	Шатун 225H		1
57	587 91 39-01	BOLT 0 16X32		4
58	587 90 89-01	Кронштейн		1
59	587 91 51-01	Пружина		1
60	587 91 14-01	ROD		1
61	587 91 50-01	Кронштейн		1
62	587 90 90-01	Кронштейн		1
63	587 58 59-01	FLAP		1
64	587 91 33-01	HEXAGON NUT		4

Спр. №	Код	Описание	Замечание	КОЛ Наб.
65	587 58 58-01	КНОВ		4
66	587 91 43-01	Шайба		2
67	587 91 42-01	BOLT 0 16X32		2
68	587 91 37-01	BOLT 0 16X32		3
69	587 91 11-01	Прокладка		3
70	587 91 61-01	Продукция		1
71	587 58 63-01	GRASSBAG		1
72	587 91 18-01	Кронштейн		1
73	587 58 60-01	КРЫШКА		1
74	587 91 23-01	SCREW		1
75	587 58 61-01	Передняя ручка 371K		1
76	587 91 06-01	ROPE		1
77	587 90 91-01	Передняя ручка 371K		1
78	587 90 95-01	Шайба		1
79	587 91 04-01	Пластина		1
80	587 91 60-01	THROTTLE CABLE		1
81	587 91 59-01	DRIVE CABLE		1
82	587 91 36-01	BOLT 0 16X32		2
83	587 90 92-01	Рукоятка		1
84	587 91 32-01	Гайка		1
85	587 91 44-01	Резиновое кольцо		1
86	587 91 03-01	HOLDER		1
87	587 91 40-01	BOLT 0 16X32		1
88	587 90 93-01	Рукоятка		1
89	587 91 05-01	HANDLE GRIP		1
90	587 90 94-01	Передняя ручка 371K		1
91	587 99 34-01	Шайба		2
92	587 99 35-01	Шайба		2
93	587 99 25-01	Сальник		4