




SPARE PARTS LIST

LAWN MOWERS: CONSUMER
WALK-BEHINDS


LC353 V, 967239101, 2015

D LC 353V
Collect parts



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	502 24 59-01	AXLE		1
2	502 24 47-01	Пружина		1
3	504 59 81-01	COVER LID		1
4	502 43 53-01	SCREW ITXPANT		1
5	575 88 55-01	Шайба		1
6	501 96 77-01	HATCH		1
7	501 98 77-01	GRASSBAG		1
8	505 39 67-01	CHUTE		1
10	502 30 50-01	CAP NUT		2
11	505 19 84-01	Шайба		2
12	505 15 61-01	SCREW		2
13	732 25 16-01	HEXAGON LOCKING NUT		2
14	505 19 84-01	Шайба		2
15	505 55 77-01	SCREW ITXPANTT		2
16	502 43 53-01	SCREW ITXPANT		7
17	501 98 76-01	GRASSBAG		1
18	502 44 71-01	GRASSBAG		1
19	505 39 69-01	CHUTE		1

C LC 353V
Engine




ENGINE


LC353 V, 967239101, 2015

Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	516 04 36-08	Наклейка		1
2	.	TBD	100602-0164-B8, B&S	1
3	531 21 28-51	SCREW		3
4	504 46 05-01	WOODRUF KEY		1
5	504 59 13-02	BLADE SUPPORT		1
7	501 96 81-01	BELT COVER		1
8	505 52 46-01	SCREW ITXPANTT		2
9	510 43 64-10	MOWER BLADE		1
11	531 20 72-37	Шайба		1
12	531 20 66-49	SCREW		1

B LC 353V
Handle



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	584 86 14-01	CONTROL		1
2	584 61 75-02	BAIL		1
3	584 86 00-01	Рукоятка и тросик		1 1
7	585 40 20-07	Провод		1
8	504 13 83-01	Привод дросселя		2
9	505 53 11-01	Ручка серебряная		2
10	580 77 62-01	ADJUSTMENT DISC		2
11	502 43 52-03	SCREW ITXPANTT		4
12	522 91 94-01	LOCKING NUT		2
13	504 63 81-01	Пружина		2
14	505 52 46-01	SCREW ITXPANTT		2
16	584 82 49-01	Наклейка		1
17	577 70 14-01	Кронштейн		1
18	574 39 14-01	SCREW ITXPANT		2
19	584 21 12-01	Проставка		1
20	577 27 66-02	Провод		1 1
21	531 20 51-69	PIN RETAINING SCREW		1
22	731 23 16-01	HEXAGON NUT		1
23	531 20 49-61	Шайба		2
24	502 30 50-01	CAP NUT		1



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	502 43 52-01	SCREW ITXPANTT		17
2	504 05 56-01	NUT FLANGE		1
3	504 05 33-01	Шкив		1
4	501 98 66-05	Ремень приводной 272К 14"		1
5	522 02 46-01	Пружина		2
6	504 04 83-01	Привод дросселя		1
7	504 04 80-01	GEARBOX		1
8	502 43 53-01	SCREW ITXPANT		2
9	522 02 40-01	Гайка		2
10	504 04 87-01	Пружина		1
11	504 04 86-01	Кронштейн		1
13	504 00 00-04	HANDLE SUPPORT		1
14	531 20 58-48	Соединительная деталь		1
15	522 61 23-01	BELT GUIDE		1
16	504 64 15-01	SKID PLATE		1
17	504 00 32-04	HANDLE SUPPORT		1
18	506 55 83-02	SCREW EHHFT		6
19	735 31 09-21	E-CLIP		2
21	504 62 50-01	Тяга		2
22	504 70 28-01	LOCK RING		2
23	505 22 14-01	Шайба		4
24	738 21 01-04	Съемник подшипника		8 25, 30
25	584 14 22-01	WHEEL		2
27	574 25 94-01	SCREW		4
28	584 15 93-01	CAP		4
29	584 15 94-01	NUT PROTECTION		4
30	584 61 16-01	WHEEL		2
31	504 62 41-01	Защита от пыли		4
32	544 34 23-01	PINION		2
33	504 70 98-04	LINK ARM ASSY		2
35	504 70 98-02	LINK ARM ASSY		2
36	504 62 49-01	Кронштейн		2
39	505 52 10-01	Гайка		2
40	583 90 18-01	FRONT COVER ASSY		1
41	502 62 54-01	SKID PLATE		1
42	584 81 07-02	ROD		1
44	574 40 60-01	TRANSVERSAL ROD		2
46	505 39 70-03	Крышка в сборе		1
47	735 31 36-21	WASHER		1
48	504 83 82-01	Привод дросселя		1
49	522 59 85-01	KNOB		1
50	505 20 19-02	REAR COVER		1
52	505 20 21-01	HATCH		1
53	502 43 52-01	SCREW ITXPANTT		2