




# SPARE PARTS LIST

## LAWN MOWERS

ELECTRIC LAWNMOWER POWER MAX  
42 E, 967249601, 967249622, 4076-20,  
4076-22, 2014-05

IPL, Gardena 37E, Powermax, 9672495-01, 9672495-22, 4075-20, 4075-22  
IPL, Gardena 42E, Powermax, 9672496-01, 9672496-22, 4076-20, 4076-22  
Publication Number AP1404005 replaces AP1311010



PRODUCT COMPLETE ELECTRIC LAWNMOWER POWER MAX 42 E, 967249601, 967249622,  
4076-20, 4076-22, 2014-05

Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	584 90 48-01	SWITCHBOX ASSY	EU	1
1	585 03 48-01	SWITCHBOX ASSY	CH	1
2	581 22 02-10	Передняя ручка 371K		1
3	513 85 74-00	Пластина		2
4	586 17 01-01	Винт		2
5	581 22 00-06	Передняя ручка 371K	42E	1
6	510 31 04-01	Рукоятка и тросик		1
7	579 14 59-01	COVER	Inc. Handle	1
8	581 21 97-02	GRASSBAG	42E	1
9	577 98 64-01	SAFETY FLAP		1
10	505 47 43-01	Пружина		1
11	577 71 38-01	SCREW	Pack of 5	14
12	586 17 00-01	Передняя ручка 371K		1
13	577 98 63-02	КРЫШКА		1
14	577 98 66-04	COWL		1
15	586 18 93-01	Крышка фильтра		2
16	581 21 94-02	DECK	42E	1
17	584 88 29-67	FILTER HOUSING	42E	1
18,19	586 17 07-01	MOTOR		1
20	587 98 76-01	Ремень приводной 272К 14"		1
21	513 10 37-12	LOOSE PARTS KIT	Pack of 2	2
22	581 21 75-02	DECK	42E	1
23	577 29 86-01	SCREW KIT	Pack of 5	9
24	575 58 21-67	Втулка		1
25	585 26 53-01	AXLE	42E	1
26	575 58 20-67	Втулка		1
27	575 58 23-01	ROD		1
28	510 80 51-00	Пружина		1
29	513 10 91-67	Ручка серебряная		2
30	581 21 81-02	ARM		1
31	581 21 82-03	КРЫШКА		1
32	581 21 79-01	AXLE	42E	1
33	581 21 80-67	Втулка		1
34	581 22 08-02	Заглушка		1
35	513 91 89-00	Шайба		4
36	586 17 08-01	Колесо	42E	2
37	577 98 83-06	CAP		2
38	586 17 10-01	Колесо	42E	2
39	581 21 89-06	ШАПКА ВЯЗАНАЯ		2
40	577 71 37-01	WASHER STARLOCK	Pack of 4	4
41	586 61 12-01	Нож для обрез.веток 80 см		1
42	577 71 39-01	BOLT 0 16X32		1
.	512 83 12-34	LOOSE PARTS KIT		1