




SPARE PARTS LIST

LAWN MOWERS

ACCU RECHARGEABLE LAWNMOWER
POWERMAX LI 40-32, 5033,

GARDENA Accu Rasenmäher PowerMax Li-40/32 Art.-Nr. 5033



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	590 07 28-01	CHARGER	9845-00.701.00	1
2	590 07 26-01	BATTERY	9842-00.701.00	1
2	590 07 27-01	BATTERY	9843-00.701.00	1
3	582 24 13-01	CHUTE	5032-00.600.15	1
3,8,20,21,24,25,63	590 16 30-01	Набор инструментов 235R	5033-00.901.00	1
4	582 24 12-01	Ящик для бензореза	5032-00.600.14	1
5	582 24 03-01	SAFETY FLAP	5032-00.600.13	1
6,7	582 24 14-01	LID ASSY	5032-00.650.00	1
8	582 24 17-01	Передняя ручка 371K	5032-00.650.03	1
9	582 23 94-01	Деталь тормоза цепи	5032-00.630.03	1
10	582 24 93-01	КРЫШКА	5033-00.630.01	1
11	582 23 93-01	Передняя ручка 371K	5032-00.630.02	1
12,29	582 70 79-01	SCREW	5032-00.600.67	1
13	582 25 03-01	MICRO SWITCH	5032-00.630.50	1
14	582 23 97-01	Передняя ручка 371K	5032-00.630.04	1
15	589 32 86-01	Пружина	5032-00.630.53	1
16	582 23 99-01	КРЫШКА	5032-00.630.05	1
17	582 24 94-01	КРЫШКА	5033-00.630.02	1
18	582 25 06-01	CABLE ASSY 2035	5033-00.631.00	1
20	589 32 77-01	Шайба	5032-00.600.71	1
21	582 24 53-01	WING KNOB	5032-00.670.00	1
22,23	590 16 25-01	Передняя ручка 371K	5032-00.902.00	1
24	582 25 65-01	BOLT 0 16X32	5032-00.600.66	1
25	582 25 67-01	Пластина	5032-00.600.17	1
26	582 24 20-01	WING KNOB	5032-00.660.00	1
27	582 70 82-01	Гайка	5032-00.600.68	1
28	582 23 51-01	Шайба	5032-00.600.52	1
30	582 24 04-01	Пружина	5032-00.600.64	1
31	582 24 00-01	Кронштейн	5032-00.600.12	1
34	582 23 59-01	Ось тормоза цепи	5032-00.600.09	1
35	582 22 95-01	Колесо	5032-00.600.05	1
36	582 25 69-01	Шайба	5034-00.600.54	1
37	582 26 48-01	CAP	5034-00.600.03	1
38	582 23 66-01	KNOB	5032-00.600.11	1
39	582 22 87-01	Кронштейн	5032-00.600.02	1
40	582 23 60-01	Крышка фильтра	5032-00.600.60	1
41	582 22 94-01	Колесо	5032-00.600.04	1
43	582 26 47-01	CAP	5034-00.600.02	1
45	582 23 58-01	Пружина	5032-00.600.59	1
46	582 23 48-01	HEIGHT ADJUSTER	5032-00.620.00	1
47	582 23 43-01	Пружина	5032-00.600.58	1
48	582 23 45-01	Редуктор 343R 345Rx	5032-00.600.07	1
49	589 56 21-01	Крышка фильтра	5032-00.600.69	1
50	582 25 75-01	BOLT 0 16X32	5032-00.600.56	1
51	582 70 81-01	Шайба	5032-00.600.70	1
52	590 07 21-01	MOWER BLADE	4100-00.701.00	1
53	582 24 89-01	IMPELLER	5033-00.600.01	1
55	582 25 08-01	Пружина	5033-00.640.52	1
56	582 70 84-01	SCREW ENHM	5033-00.600.51	1
57	582 24 91-01	MOTOR ASSY	5033-00.610.00	1
59	582 25 96-01	CONTROL	5033-00.620.00	1
60	582 70 85-01	Заглушка	5033-00.642.00	1
62	582 26 11-01	MICRO SWITCH	5033-00.641.53	1
63	582 24 97-01	KNOB	5033-00.600.18	1
64	582 26 02-01	Корпус пружины	5033-00.640.02	1
66	582 24 10-01	Крышка фильтра	5032-00.640.50	1
69	582 24 96-01	FRONT COVER	5033-00.640.01	1
71	582 25 00-01	BATTERY	5033-00.640.04	1