




SPARE PARTS LIST

LAWN MOWERS

ACCU RECHARGEABLE LAWNMOWER
POWERMAX LI 40-41, 5041,

GARDENA Accu Rasenmäher PowerMax Li 40/41 Art.-Nr. 5041



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	590 07 28-01	CHARGER	9845-00.701.00	1
2	590 07 27-01	BATTERY	9843-00.701.00	1
4	579 68 41-01	BOLT 0 16X32	57-96.841.01	1
5	579 68 42-01	Шайба	57-96.842.01	1
6	579 68 43-01	Шайба	57-96.843.01	1
7	590 07 24-01	MOWER BLADE	4104-00.701.00	1
8	579 68 45-01	BLADE SUPPORT	57-96.845.01	1
9	589 46 97-01	CAP	5041-00.600.01	1
10	589 99 83-01	LOCKING BOLT	5041-00.600.02	1
11	587 91 29-01	Игольчатый подшипник	58-79.129.01	1
12	589 46 96-01	Колесо	5041-00.600.06	1
13	587 91 46-01	Шайба	58-79.146.01	1
14	579 68 46-01	BOLT 0 16X32	57-96.846.01	1
15	579 68 47-01	Пластина крепления ножа	57-96.847.01	1
16	589 99 88-01	FRONT AXLE ASSY	5041-00.600.04	1
17	587 91 31-01	LOCKING BOLT	58-79.131.01	1
18	579 68 49-01	Пластина крепления ножа	57-96.849.01	1
19	589 46 99-01	CAP	5041-00.600.05	1
20	589 46 98-01	Колесо	5041-00.600.03	1
21	587 91 27-01	Шайба	58-79.127.01	1
22	590 08 61-01	SCREW	5041-00.600.10	1
23	502 50 27-01	Рукоятка и тросик	50-25.027.01	1
24	587 58 57-02	KNOB	5041-00.600.08	1
25	589 99 89-01	REAR AXLE ASSY	5041-00.600.07	1
26	587 91 79-01	КРЫШКА	58-79.179.01	1
28	587 91 26-01	SCREW	58-79.126.01	1
29	587 99 24-01	FIXING PLATE	58-79.924.01	1
30	587 91 09-01	FIXING PLATE	58-79.109.01	1
31	579 68 51-01	BOLT 0 16X32	57-96.851.01	1
32	587 90 99-01	SEGMENT	58-79.099.01	1
33	579 68 52-01	Гайка	57-96.852.01	1
34	579 68 54-02	DECK	5041-00.600.09	1
35	587 91 58-01	TUBING	58-79.158.01	1
36	587 91 49-01	Пружина	58-79.149.01	1
38	589 99 92-01	Шатун 225H	5041-00.600.12	1
40	587 91 51-01	Пружина	58-79.151.01	1
41	587 91 50-01	Кронштейн	58-79.150.01	1
42	587 91 34-01	LOCK NUT	58-79.134.01	1
43	579 68 58-01	Гайка	57-96.858.01	1
44	579 68 59-01	HOLDER	57-96.859.01	1
45	579 68 60-01	Шайба	57-96.860.01	1
46	579 68 61-01	BOLT 0 16X32	57-96.861.01	1
47	579 68 62-01	Ремонтный блок	57-96.862.01	1
48	590 08 65-01	SCREW	5041-00.600.13	1
49	579 68 65-01	Шайба	57-96.865.01	1
50	579 68 64-01	ELECTRONIC BOX	57-96.864.01	1
51	590 08 69-01	Шайба	5041-00.620.02	1
52	589 47 00-01	КРЫШКА	5041-00.600.24	1
57	582 02 92-01	Тросик	58-20.292.01	1
58	579 68 57-01	Пластина	57-96.857.01	1
59	579 68 56-01	Кронштейн	57-96.856.01	1
60	590 08 68-01	SCREW	5041-00.600.23	1
61	589 99 95-01	STARTING SOLENOID	5041-00.600.14	1
62	579 68 68-01	Пластина	57-96.868.01	1
63	579 68 69-01	KEY SWITCH	57-96.869.01	1
65	501 49 01-01	KEY	50-14.901.01	1
67	589 99 97-01	STRIP	5041-00.600.20	1
68	589 99 96-01	Крышка фильтра	5041-00.600.19	1
69	501 48 98-01	HINGE	50-14.898.01	1
70	589 47 02-01	COVER	5041-00.600.22	1
71	501 49 02-01	ШАПКА ВЯЗАНАЯ	50-14.902.01	1
72	579 68 70-01	Пружина	57-96.870.01	1
75	579 68 63-01	SCREW	57-96.863.01	1
76,83	590 07 48-01	KNOB ASSY	5041-00.651.00	1

Спр. №	Код	Описание	Замечание	КОЛ Наб.
78	590 01 01-01	Передняя ручка 371K	5041-00.600.31	1
79	579 68 79-01	Гайка	57-96.879.01	1
80	590 00 96-01	HOLDER	5041-00.600.30	1
81	590 00 00-01	BOLT 0 16X32	5041-00.600.26	1
82	590 08 70-01	Шайба	5041-00.620.13	1
84	590 00 92-01	Передняя ручка 371K	5041-00.600.29	1
85	590 01 14-01	BOLT 0 16X32	5041-00.620.01	1
87	589 57 80-01	HANDLE SUPPORT	5041-00.620.12	1
88	590 01 24-01	Втулка	5041-00.620.15	1
89	590 01 23-01	Провод	5041-00.620.14	1
90	501 49 12-01	КРЫШКА	50-14.912.01	1
91	501 49 11-01	КРЫШКА	50-14.911.01	1
92	589 57 90-01	КНОВ	5041-00.620.06	1
93	589 57 84-01	КРЫШКА	5041-00.620.04	1
94	590 01 25-01	BAIL ARM ASSY	5041-00.620.16	1
95	590 01 19-01	Пружина	5041-00.620.09	1
96	589 57 88-01	BLOCK	5041-00.620.07	1
97	590 01 17-01	Пружина	5041-00.620.08	1
98	589 57 86-01	КРЫШКА	5041-00.620.05	1
99	590 01 21-01	Провод	5041-00.620.10	1
100	501 05 57-01	HOLDER	50-10.557.01	1
101	587 58 60-02	КРЫШКА	5041-00.600.33	1
102	590 01 28-01	Ящик для бензореза	5041-00.600.32	1
103	587 91 18-01	Кронштейн	58-79.118.01	1
104	589 47 07-01	SAFETY FLAP	5041-00.600.37	1
105	587 58 61-02	Передняя ручка 371K	5041-00.600.36	1
106	590 09 35-01	SCREW	5041-00.600.34	1
107	579 68 87-01	Шайба	57-96.887.01	1
108	590 08 72-01	Шайба	5041-00.600.35	1
109	590 00 78-01	Кольцо	5041-00.600.27	1
	590 03 94-01	LOOSE PARTS KIT	5041-00.650.00, not shown in image	1
	590 08 64-01	Заглушка	5041-00.600.11, not shown in image	1