


AR 53 TK (K800) - Illustrated parts list (Restyling 2011)




AR 53 TK (K800) - Illustrated parts list (Restyling 2011)



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060104A	Handlebar				
2	1	66060106R	Brake lever				
3	2	3914006R	Nut				
4	1	66060165BR	Throttle				
5	1	3906053	Screw				
6	2	66060231	Band				
7	1	66060365R	Engine brake wire				
8	2	3910015R	Screw				
9	4	3916008R	Washer				
10	2	4119013AR	Knob				
11	1	66060254	Cover				
12	15	3960031R	Screw				
13	2	3045027R	Fastener				
14	1	66062026	Cover				
15	1	66060060	Spring				
16	1	66060055	Deflector axle				
17	1	66060394	Attacm. set				
18	1	66090155A	Anular buffer				
19	4	3914010R	Nut				
20	4	3806065	Screw				
21	4	66060008A	Plate				
22	1	66060003AR	Deck				
23	1	66062096	Cover				
24	1	66060260	Grassbag				
25	1	66060255	Frame				
26	1	66060131	Hub Ø22,2				
27	1	66060413R	Mulching Blade 53	matr. 6161074307			BT5-067- 03/11
28	1	3906162R	Screws				
29	1	66060384R	Washer				
30	1	66060024B	Compl. rear axle				
31	2	3026007	Ring				
32	1	66060043	Spring				
33	1	66060027	Rod				
34	2	3027001R	Washer				
35	8	66030081R	Bearing				
36	2	66070364	Wheel kit				
37	2	3806077	Screw				
38	1	3906083	Screw				
39	2	66070298R	Wheel cover				
40	1	3960013R	Screw				
41	1	66060355A	Knob kit				
42	1	3918017	Washer				
43	1	66060037AR	Female thread				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
44	1	66060038	Washer				
45	1	66060039AR	Screw				
46	2	66070362	Wheel kit				
47	1	66060020B	Front axle				
48	1	66060007	Bushing				
49	1	66060375	Guard kit				
50	2	3960040R	Screw				
51	1	66060410	Hub with sheet				
52	1	66060256	Support				
53	1	66062027	Cover				
54	1	66062098	Labels set				
55	2	66060030R	Bushing				
56	4	3024012	Ring				
57	1	66060031	Left sprocket				
58	1	66060293AR	Wheel cover				
59	1	3047028R	Belt				
60	1	66060419R	Pulley				BT5-056-06/09, BT5-062-01/10
61	1	3022020	Pin				BT5-056-06/09
62	1	66060032	Right sprocket				
63	1	66060044R	Spring				BT5-056-06/09
64	2	66060010R	Pin				
65	1	66060360DR	Transmission				BT5-056-06/09, BT5-062-01/10
66	1	66060105	Lever				
67	1	66060357R	Traction cable				BT5-056-06/09
68	1	8202126R	Key				
69	8	66060110R	Spacer				
70	2	3045033R	Retainer washer				
71	2	66070299R	Wheel cover				
72	1	66060118R	Ring				
73	2	3918013	Washer				
74	1	3960087AR	Screw				BT5-056-06/09
75	1	66060372R	Mulching cap				

AR 53 TK (K800) - Illustrated parts list





AR 53 TK (K800) - Illustrated parts list



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	66060104A	Handlebar				
2	1	66060106	Brake lever				
3	2	3914006R	Nut				
4	1	66060164BR	Compl. throttle				
5	1	3906164R	Screw				
6	2	66060231	Band				
7	1	66060365R	Engine brake wire				
8	2	3910015R	Screw				
9	4	3916008R	Washer				
10	2	4119013AR	Knob				
11	1	66060254	Cover				
12	15	3960031R	Screw				
13	2	3045027R	Fastener				
14	1	66062026	Cover				
15	1	66060060	Spring				
16	1	66060055	Deflector axle				
17	1	66060394	Attacm. set				
18	4	66030057	Bearing				
19	4	3914010R	Nut				
20	4	3806065	Screw				
21	4	66060008	Plate				
22	1	66060003AR	Deck				
23	1	66062096	Cover				
24	1	66060260	Grassbag				
25	1	66060255	Frame				
26	1	66060131	Hub Ø22,2				
27	1	66060413R	Mulching Blade 53	matr. 6161074307			BT5-067- 03/11
28	1	3906162R	Screws				
29	1	66060384R	Washer				
30	1	66060024B	Compl. rear axle				
31	2	3026007	Ring				
32	1	66060043	Spring				
33	1	66060027	Rod				
34	2	3027001R	Washer				
35	4	66030081R	Bearing				
36	2	66062097	Wheel kit				
37	2	3806077	Screw				
38	1	3906083	Screw				
39	2	66110278R	Wheel cover				
40	1	3960013R	Screw				
41	1	66060355A	Knob kit				
42	1	3918017	Washer				
43	1	66060037AR	Female thread				

Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
44	1	66060038	Washer				
45	1	66060039AR	Screw				
46	2	66110301	Wheel				
47	1	66060020B	Front axle				
48	1	66060007	Bushing				
49	1	66060375	Guard kit				
50	2	3960040R	Screw				
51	1	66060034	Cover				
52	1	66060256	Support				
53	1	66062027	Cover				
54	1	66060035	Hub				
55	2	66060030R	Bushing				
56	4	3024012	Ring				
57	1	66060031	Left sprocket				
58	1	66060293AR	Wheel cover				
59	1	3047028R	Belt				
60	1	66060419R	Pulley				BT5-056-06/09, BT5-062-01/10
61	1	3022020	Pin				BT5-056-06/09
62	1	66060032	Right sprocket				
63	1	66060044R	Spring				BT5-056-06/09
64	2	66060010R	Pin				
65	1	66060360DR	Transmission				BT5-056-06/09, BT5-062-01/10
66	1	66060105	Lever				
67	1	66060357R	Traction cable				BT5-056-06/09
68	1	8202126R	Key				
69	8	66060110R	Spacer				
70	2	3045033R	Retainer washer				
71	2	66030145R	Wheel cover				
72	1	66060118R	Ring				
73	2	3918013	Washer				
74	1	3960087AR	Screw				BT5-056-06/09
75	1	66062098	Labels set				
76	1	66090155A	Anular buffer				BT5-056-06/09

AR 53 TK (K800) - Cylinder head and valve




AR 53 TK (K800) - Cylinder head and valve



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	2	L66150086	Arm assy.				
2	2	L66150099	Slide				
3	1	L66150102	Camshaft assy.				
4	1	L66150100	Washer				
5	1	3055123	Spark plug				
6	4	L66150008	Stud				
7	1	L66150221	Head comp.cylinder				
8	4	L66150005	Screw				
9	4	L66150001	Screw				
10	2	L66150012	Bushing				
11	2	L66150241	Stud				
12	1	L66150002	Cover				
13	2	L66150087	Spring holder				
14	2	L66150089	Seal				
15	2	L66150090	Spring				
16	1	L66150091	Intake valve				
17	1	L66150094	Exhaust valve				
18	1	L66150096	Plate				
19	2	L66150098A	Equalizer rod				
20	1	L66150245	Gasket set				
21	1	66060414	19 x 21 mm wrench				
22	1	L66150471	Gasket				

AR 53 TK (K800) - Cylinder and crankcase




AR 53 TK (K800) - Cylinder and crankcase



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150242	Crankcase assy				
2	3	L66150043	Bushing				
3	3	L66150042	Bushing				
4	1	L66150245	Gasket set				
5	1	L66150018	Stud				
6	2	L66150019	Stud				
7	1	L66150020	Reed valve				
8	1	L66150021	Washer				
9	1	L66150022	Screw				
10	1	L66150024	Filter,breather				
11	1	L66150037	Spring lock				
12	1	L66150244	Cap,breather chamber				
13	2	L66150029	Screw				
16	1	L66150246	Hose				
17	1	L66150034	Shaft,governor arm				
18	1	L66150035	Washer				
19	1	L66150036	Gasket				
20	1	L66150243	Guard				
21	2	L66150251	Screw				
22	1	L66150017	Seal ring				

AR 53 TK (K800) - Crankcase cover




AR 53 TK (K800) - Crankcase cover



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150247	Cover				
2	4	L66150047	Screw				
3	1	L66150069	Screw				
4	1	L66150049	Plate,governor holder				
5	2	L66150050	Bushing				
6	1	L66150051	Screw				
7	1	L66150052	Washer				
8	1	L66150068	Cap assy				
9	1	L66150067	Oil cap				
10	1	L66150053	Washer				
11	1	L66150054	Shaft,governor				
12	1	L66150055	Seeger				
13	1	L66150056	Slide control				
14	1	L66150058	Governor assy				
15	1	L66150064	Screw				
16	1	L66150245	Gasket set				
17	2	L66150061	Bushing				
18	1	L66150062	Deflector				
19	1	L66150063	Washer				
20	1	L66150048	Seal ring				
21	1	L66150283	Gasket				

AR 53 TK (K800) - Crankshaft and piston





AR 53 TK (K800) - Crankshaft and piston



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150071	Piston ring set				
2	2	L66150075	Snap ring				
3	1	L66150077	Piston pin				
4	1	L66150222	Piston assy				
5	2	L66150078	Bolt,connecting rod				
6	1	L66150080	Connecting rod set				
7	1	L66150085	Bearing				
8	1	L66150083	Crankshaft				
9	1	L66150081	Key				
10	1	L66150084	Washer				

AR 53 TK (K800) - Starter assy and flywheel





AR 53 TK (K800) - Starter assy and flywheel



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150248	Starter assy				
2	1	L66150144	Flywheel				
3	1	L66150146	Fan				
4	1	L66150147	Pulley				
5	1	L66150148	Nut				
6	1	L66150149	Spark plug cap				
7	1	L66150150	Wire, stopping engine				
8	1	L66150151	Ignition coil				
9	1	L66150152	Screw				
10	1	L66150153	Spring				
11	2	L66150152	Screw				
12	1	L66150228	Flyweheel brake				
13	1	L66150235	Nut				
14	1	L66150270	Handle				
15	1	L66150269	Starter rope				
16	1	L66150266	Spring, recoil starter				
17	1	L66150265	Pulley				
18	2	L66150263	Pawl				
19	2	L66150264	Spring				
20	1	L66150262	Spring				
21	1	L66150261	Washer				
22	1	L66150260	Slide				
23	1	L66150259	Screw				

AR 53 TK (K800) - Carbuirettor





AR 53 TK (K800) - Carburettor



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150117	Insulator				
2	1	L66150143	Carburetor				
3	1	L66150132	Throttle valve assy.				
4	1	L66150135	Air lever				
5		-	Not available for this product				
6	1	L66150245	Gasket set				
7	1	L66150122	Screw				
8	1	L66150212	Repair parts				

AR 53 TK (K800) - Air filter and muffler






AR 53 TK (K800) - Air filter and muffler



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150219	Muffler assy.				
2	1	L66150250	Air filter kit				
3	1	L66150245	Gasket set				
4	1	L66150165	Screw				
5	1	L66150155	Air filter				
6	1	L66150157	Filter,outer				
7	4	L66150164	Nut				

AR 53 TK (K800) - Control lever





AR 53 TK (K800) - Control lever



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150168	Screw,control adjusting				
2	1	L66150169	Spring				
3	1	L66150170	Spring				
4	1	L66150171	Plate				
5	1	L66150172	Bolt m5x16				
6	1	L66150173	Complete lever				
7	2	L66150174	Screw				
8	1	L66150175	Rod				
9	1	L66150176	Spring,throttle return b				
10	1	L66150178	Throttle rod				
11	1	L66150180	Spring				
12	1	L66150182	Control lever				
13	1	L66150183	Screw				
14	1	L66150164	Nut				

AR 53 TK (K800) - Fuel tank and cover



AR 53 TK (K800) - Fuel tank and cover



Ref.Nu	Qty	Part number	Description	Validity from	Validity till	Notes	Bulletin
1	1	L66150234	Cover				
2	1	L66150207	Clip				
3	1	L66150239	Holder, fuel tank				
4	3	L66150240	Screw				
5	1	L66150193	Cap				
6	1	L66150253	Complete tank				
7	1	L66150204	Filter				
8	1	L66150201	Stud				
9	2	L66150198	Clip				
10	1	L66150199	Hose				
11	1	L66150203	Screw				