



Pos. No	Part code (Factory)		QTY
1	GB/894.1-1986	circlip	1
2	GB/T818-2000	pan head screw	6
3	GB/T848-2002	washer	6
4	GB/T849-2002	bearing seat	2
5	GB/T850-2002	right connecting support	1
6	GB/T851-2002	press plate	2
7	GB/T889.1-2000	nut	6
8	GB/T889.2-2001	auger assembly	1
9	GB/T889.3-2002	left connecting support	1
10	GB/T845-1985	self tapping screw	4
11	GB/T276-1994	bearing	2
12	GB/T277-1995	V-belt wheel	1
13	GB/T278-1996	V-belt	1
14	GB/T96.1-2002	washer	1
15	GB/T93-1987	spring washer	1
16	GB/T818-2000	pan head screw	1
17	STG2215-101A-01	left cover	1
18	STG2215-304A-02	left wearing plate	1
19	STG2215-102A-01	snow bucket	1
20	GB/T822-2004	snow shoveling plate	1
21	GB/T845-1985	self tapping screw	2
22	STG2215-901A-01	led lamp	2
23	STG2215-305A-02	right wearing plate	1
24	STG2215-104A-01	small cover	1
25	GB/T845-1985	self tapping screw	2
26	STG2215-105A-01	lamp cup	2
27	STG2215-106A-01	lampshade	2
28	STG2215-107A-01	right cover	1
29	T36024216003	self tapping screw	10
30	GB/T889.1-2000	nut	1
31	GB/T889.2-2000	tension spring	1
32	GB/T889.3-2000	tension spring	1
33	T20011202010	washer	1
34	STG2215-307A-01	tension support	1
35	GB/T276-1994	bearing	2
36	STG2215-308A-01	tensionwheel axle	1
37	GB/T845-1985	self tapping screw	2
38	TS200000010	wire press block	1
39	GB/T845-1985	self tapping screw	1
40	STG2215-902A-01	wire joint	1
41	GB/T845-1985	self tapping screw	4
42	GB/T845-1985	self tapping screw	2
43	STG2215-903A-03	transforme	1
44	GB/T845-1985	self tapping screw	3
45	GB/T845-1985	self tapping screw	3
46	GB/T955-1986	gearbox cover	1
47	GB/T455-1986	big belt wheel	1
48	GB/T355-1986	big gear	1
49	GB/T818-2000	pan head screw	3
50	GB/T848-2002	washer	3
51	GB/T93-1987	spring washer	3
52	GB/T276-1994	bearing	1
53	GB/894.1-1986	circlip	1
54	GB/T276-1994	bearing	1
55	GB/T845-1985	self tapping screw	2
56	GB/T96.1-2002	washer	2
57	STG2215-309A-01	small belt wheel axle	1
58	GB/T98.1-2004	small gear	1
59	GB/T819.1-2000	sunk screw	2
60	GB/T818-2000	pan head screw	2
61	GB/T919-2001	gearbox	1
62	GB/T845-1985	self tapping screw	4
63	STG2215-JY-05	gearbox support	1
64	GB/T995-1987	motor	1
65	GB/T845-1985	self tapping screw	5
66	STG2215-JY-12	strap	1

67	STG2215-108A-01	waterproof cover	1
68	GB/T845-1985	self tapping screw	4
69	GB/894. 1-1986	circlip	2
70	GB/T995-1991	wheel	2
71	STG2215-310A-02	axle	1
72	GB/T5789-1986	bolt	2
73	GB/T96. 1-2002	washer	2
74	GB/T889. 1-2000	nut	2
75	STG2215-140A-01	roller bracket	2
76	T102700060002	nut	4
77	STG2215-JY-13	washer	2
78	GB/T5789-1986	bolt	2
79	GB/T5789-1986	bolt	2
80	STG2215-312A-01	lower handle	1
81	T42070848000	cup head square neck bolt	4
82	STG2215-138A-05	knob	4
83	STG2215-313A-01	middle handle	1
84	STG2215-139A-01	shovel clamp	2
85	STG2215-130A-02	shovel	1
86	GB/T845-1985	self tapping screw	2
87	STG2215-314A-01	upper handle	1
88	GB/T900-1987	switch box compound	1
89	GM004-102A-KB01	cord hook	1
90	GM003-125A-05	wire clip	3
91	STG2215-JY-17-01	rubber ring	2
92	STG2215-137A-01	swing handle cap	1
93	T23010000800	circlip	1
94	STG2215-315A-02	swing handle	1
95	T50010301600	pin	1
96	STG2215-136A-03	swing pole	1
97	STG2215-318A-02	pin-hair	2
98	STG2215-317A-02	middle pole	1
99	GB/T845-1985	self tapping screw	2
100	STG2215-JY-21	steering shrapnel	1
101	GB/T845-1985	self tapping screw	2
102	STG2215-111A-01	swing gear support	1
103	GB/T901-1987	lock ring	1
104	GB/T901-1988	swing gear	1
105	GB/T889. 1-2000	nut	1
106	GB/T96. 1-2002	washer	1
107	GB/T12-1988	cup head square neck bolt	1
108	GB/T12-1989	discharge chute cover	1
109	GB/T12-1988	cup head square neck bolt	1
110	866005-07	knob	1
111	866305-03	seal ring	1
112	GB/T13-1991	discharge chute	1
113	T36024216003	self tapping screw	14
114	STG2215-113A-07	shell	1
115	STG2215-114A-01	snow bucket cover	1
116	GB/T845-1985	self tapping screw	6
117	STG2215-230A-01	dustproof sponge	4