

GENUINE SPARE PARTS

STAR 36D Model Year 2011

- Use GLOBAL GARDEN PRODUCT Genuine Spare Parts specified in the parts list for repair and/or replacement.
- The contents described in the parts list may change due to improvement.
- The drawings of the spare parts are only indicative and might not represent the part in question exactly.
- The indications "right" - "left" - "front" - "rear" refer to the position of the operator when using the machine.
- When placing orders of parts for repair and/or replacement, make sure that the illustrated parts list is the one applying to the machine's year of manufacture, as shown on the identification plate attached to the machine.

COPYRIGHT by GLOBAL GARDEN PRODUCTS

All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from GLOBAL GARDEN PRODUCTS.


...THINKING GREEN





STAR 36D

Engine






STAR 36D

Engine

Pos.	Part no.	Q.ty	Description	Remarks
1	2135040	12	Screw	
2	4540800	1	Trasm. Support Case	
4	2132500	1	Screw	
5	2312120	1	Washer	
6	3745530	4	Grommet	
7	2653210	2	Screw	
8	3654040	1	Spring Mod.Piston Ass.Y Ø 42	
9	3660430/1	2	Clutch Unit Mod.Piston Ass.Y Ø 42	
10	2321230	2	Washer	
11	2135060	2	Screw	
12	2321150	2	Washer	
13	3211015	1	Elettronic Coil	
14	3211080	1	Spark Plug Cable	
15	3782040	1	Wire Jacket	
16	3211415	1	Earth Cable	
17	4251480/1	1	Flywheel Ass.Y (Incl. 7,9,10)	
18	2670120	2	Nut	
19	2135050	3	Screw	
20	3121070	2	Seal Ring	
21	3745130	1	Grommet	
22	8521010	1	Cranckase Ass.Y	
23	3151010	1	Flywheel Key	
25	3116100	1	Needle Bearing	
27	8250840	1	Crankshaft (Incl. 25)	
28	3112240	2	Bearing	
29	3750280	1	Massathread Guide	
30	3724050	1	Gasket	
31	2432040	5	Nut	
32	2123100	3	Screw	
33	3654050	2	Spring	
34	3749570	2	Starter Hook	
35	8540810	1	Starter Cup Ass.Y (Incl.32-34)	
36	2135180	1	Screw	
37	4563660	1	Cylinder Cover Ass.Y Yellow	
38	4122120	1	Muffler	
41	3724340	1	Muffler Gasket	
42	3744850	1	Spark Plug Cover	
43	3657530	1	Spark Plug Spring	
44	3210024	1	Spark Plug	
45	2135150	2	Screw	
46	3724260	1	Cylinder Gasket	
47	3123150	1	Piston Ring X Mod. Ø 38	
48	3158260	1	Piston Pin	
49	3356050	2	Circlip	
50	8541120	1	Piston Ass.Y Ø 38 (Incl.26,47-49)	
51	8541110	1	Cylinder-Piston Ass.Y Ø 38 (Incl.50)	
52	4253290	1	Intake Filter	
53	8745541	1	Grommet Ass.Y	
54	8741370	1	Fuel Cap Ass.Y	
55	4252470	1	Fuel Tank Ass.Y (Incl.52-54)	
61	2112310	2	Screw	
62	8724340	1	Gasket Set (Incl.30,41,46)	
63	4612587	1	Flange	



STAR 36D
Engine






STAR 36D

Engine

Pos.	Part no.	Q.ty	Description	Remarks
1	3724360	1	Intake Manif-Gasket	
2	3750410	1	Intake Manifold	
3	2670280	2	Nut	
4	2135050	2	Screw	
5	3724400	2	Gasket	
6	3785070	1	Heat Block	
7	4353270/1	1	Carburettor	
8	8750390	1	Air Filter Holder	
9	2312090	3	Washer	
10	2135250	2	Screw	
11	3781600	1	Air Filter	
12	4563670	1	Filter Cover Yellow	
13	2123100	3	Screw	
14	3613420	1	Washer	
15	4562220	1	Starter Pulley	
16	3723640	1	Disc	
17	4611480	1	Spring	
18	8563650	1	Starter Recoil Case	
19	2135040	12	Screw	
20	3784030	1	Starter Cord	
21	3750067	1	Starter Handle	
22	3745530	4	Grommet	
23	4252680	1	Starter Ass.Y (Incl. 13-22)	
24	3744870	1	Primer	
25	4353150	1	Gasket-Diaph. Set	
30	2461030	2	Nut	



STAR 36D
Handle-transmission









STAR 36D

Handle-transmission

Pos.	Part no.	Q.ty	Description	Remarks
1	8563830	1	Handle Ass.Y	
2	2123030	1	Screw	
3	2135050	1	Screw	
4	12154330/0	1	Nut	
5	3210970	1	Stop Switch	
6	3743431/1	1	Throttle Lever	
7	3743441	1	Safety Lever	
8	3654270/1	1	Spring	
9	3654280/1	1	Spring	
10	4252570	1	Wire Ass.Y	
11	3786220	1	Wire Sheath	
12	3211590	1	Coil-Switch Cable (Red)	
13	3211600/1	1	Earth Cable (Black)	
14	4252840/1	1	Handle	
15	3744860/1	1	Left Knob	
16	2112580	1	Screw	
17	3750480	1	Wing Nut	
18	8521070	1	Handgrip Support Ass.Y	
19	2126050	1	Screw	
20	3654530	1	Spring	
21	3353080	1	Seeger Ring	
22	3112170	1	Bearing	
23	3L8520990/3	1	Transmission Hub Ass.Y	
24	2135150	1	Screw	
25	2432030	1	Nut	
26	2135160	4	Screw	
27	3744330	1	Rear Shock Absorber	
28	4563850/2	1	Transmission Housing	
29	3744320	3	Front Shock Absorber	
30	3615190	1	Handle Fixing Plate	
31	4563860	1	Front Housing Support	
32	2135060	2	Screw	
33	12154330/0	2	Nut	
34	4121861/1	1	Clutch	
35	3642191	1	Bearing Hub	
36	4251400	1	Trasmission Shaft	
37	4251204	1	Trasmission Pipe Ass.Y	
38	3L8563570/1	1	Safety Cover Ass.Y	
39	2135030	1	Screw	
40	2312150	1	Washer	
41	2432040	1	Nut	
42	3615000	1	Line Cutter	
43	2312150	2	Washer	
44	2135060	2	Screw	
45	4253440	1	Harness	
46	123046000/0	1	Harness	



STAR 36D
Gear case






STAR 36D

Gear case

Pos.	Part no.	Q.ty	Description	Remarks
1	4252780/1	1	Gear Case Assy	
1	4252780/1	1	Gear Case Assy	
7	2135050	2	Screw	
8	2653090	1	Screw	
9	2653460	1	Screw	
15	3121170	1	Oil Seal	
16	3641700/1	1	Collar	
17	3641640	1	Upper Ring Nut	
18	3612640	1	Lower Ring Nut	
19	4560610	1	Stabilizer	
20	2321230	1	Washer	
21	2653170	1	Screw	
22	4611880	1	4 Teeth Disc 25 Cm	
31	4353240/1	1	2 Hedges Nylon Head	



STAR 36D
Pruner tool






STAR 36D

Pruner tool

Pos.	Part no.	Q.ty	Description	Remarks
1	6910500	1	Transmission Case Ass.Y Ø24	
2	6910502	1	Chain Housing	
3	6910503	1	Oil Tank	
4	6910504	1	Cover Ø24	
5	6910506	1	Flange	
6	6910507	1	Screw	
7	6910508	1	Oil Pump Ass.Y	
8	4112610	1	"Guide Bar 10""	
9	4113551	1	"Chain 10""	



STAR 36D
"All Cutting" tool





STAR 36D

"All Cutting" tool

Pos.	Part no.	Q.ty	Description	Remarks
1	6910520	1	Blade Ass.Y	
2	6910521	1	Transmission Shaft Ass.Y	
3	6910524	1	Gear Case Ass.Y	
4	6910523	1	Lever+Regulation Rod	
5	4252640	1	Coupling	
6	2382430	1	Spacer	