













SPARE PARTS LIST

BRUSHCUTTERS/CLEARING SAWS

135 R

R2 135 R, 336 FR
ACCESSORIES







ACCESSORIES

135 R


Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	501 19 22-01	Штуцер для опрессовки		1
2	531 00 92-48	FILTER OIL		1
3	503 97 65-01	Смазка для кустореза Jon		1
4	502 28 59-01	HOUSING		1
5	503 80 17-01	Смазка для кустореза Jon		1
6	537 36 21-02	COMBINATION WRENCH		1
7	544 35 91-01	Защита		1
8	537 31 29-01	Защита		1
9	503 89 01-02	Чашка ограничительная		1
10	537 21 62-01	ПОДВЕСКА КУСТОРЕЗА R		1
10	537 21 62-02	ПОДВЕСКА КУСТОРЕЗА R	USA	1

R1 135 R, 336 FR
ACCESSORIES



Спр. №	Код	Описание	Замечание	КОЛ Наб.	
1	501 32 04-02	SAW BLADE GUARD		1	
2	574 53 06-01	Пластина	Spare part with Captive Screw	1	1
3	573 99 43-04	SCREW IHSCFMO	Captive Screw	2	1,2
4	501 32 08-01	АДАПТЕР ДЛЯ КАНИС."АСПЕН"		1	1
5	574 53 26-01	Защита		1	1
6	503 20 02-16	SCREW IHSCFM		4	1,5
7	574 03 95-01	LOCKING NUT		4	1,5
8	537 33 16-03	SPLASH GUARD 300S		1	
9	537 39 63-03	SPLASH GUARD 300S		1	8
10	503 79 88-01	Нож для обрез.веток 80 см		1	8,9
11	503 21 07-16	SCREW IHSCFT		1	8,9
12	537 38 72-01	SNAP		4	8,9
13	537 34 94-03	Защита от разброса 322L		1	
14	503 21 68-25	SCREW IHSCFT		1	13
15	503 79 88-01	Нож для обрез.веток 80 см		1	13
16	544 12 45-01	Держатель		1	13
17	502 44 81-01	TRIMMER GUARD ASSY		1	
18	503 21 68-25	SCREW IHSCFT		1	17
19	503 79 88-01	Нож для обрез.веток 80 см		1	17


A 135 R, 336 FR
BEVEL GEAR



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	544 21 64-01	Редуктор 343R 345Rx		1	
2	537 29 59-02	Корпус редуктора		1	1, 4
3	738 21 99-00	Съемник подшипника		1	1
4	505 13 33-01	SPARE PARTS KIT		1	1
5	503 25 28-01	Съемник подшипника		1	1
6	735 31 31-10	Шайба		1	1
7	738 21 01-10	Съемник подшипника		1	1
8	738 21 01-12	Съемник подшипника		1	1
9	735 31 14-00	Шайба		1	1
10	735 31 28-10	Шайба		1	1
11	537 14 74-01	MAGNET		1	1
12	503 20 15-01	SCREW IHNM		1	1
13	574 30 68-01	Пластина		1	
14	544 08 76-01	Пластина		1	13
15	537 18 95-01	SCREW		1	13
16	732 21 16-01	Гайка		1	13
17	503 20 02-10	SCREW IHSCFM		1	13
18	574 03 95-01	LOCKING NUT		1	13
19	537 35 14-02	Шайба приводная		1	
20	537 34 35-01	Кольцо-проставка		1	
21	502 29 11-01	Нож для обрез.веток 80 см		1	
22	503 20 03-25	SCREW IHSCFM		2	


Q 135 R, 336 FR
CARBURETOR

Zama C1Q-EL45




Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	575 72 90-01	Карбюратор	Zama C1Q-EL45	1	
2	503 47 92-01	SCREW		1	1
3	537 41 72-01	Вентиль		1	1
4	544 37 24-01	Пружина		1	1
5	503 48 05-01	SCREW		1	1
6	503 97 43-01	КРЫШКА		1	1
7	504 10 56-01	DIAPHRAGM		1	1,37
8	537 02 04-01	Прокладка		1	1,37
9	537 38 73-01	Деталь карбюратора 3120		1	1
10	503 48 01-01	SCREW		1	1
11	503 48 00-01	PIN RETAINING SCREW		1	1
12	503 66 59-01	Привод дросселя		1	1
13	503 47 97-01	Вентиль		1	1
14	537 02 03-01	Пружина		1	1
15	501 32 71-01	SHAFT ASSY		1	1
16	537 37 03-01	Вентиль		1	1
17	503 48 18-01	SCREW		1	1
18	544 37 26-01	Пружина		1	1
19	544 37 25-01	Привод дросселя		1	1
20	544 42 70-01	COLLAR		1	1
21	504 10 27-01	SHAFT ASSY		1	1
22	537 01 26-01	Пружина		1	1
23	537 01 25-01	BALL		1	1
24	503 48 13-01	STRAINER		1	1
25	503 47 90-01	SCREW		1	1
26	537 41 69-01	SCREW		1	1
27	537 41 70-01	Набор колпачков карб.		1	1
28	537 38 75-01	SCREW		1	1
29	537 38 52-01	CLAMP		1	1
30	576 27 02-01	Скобка		1	1
31	537 02 00-01	Мембрана		1	1,37
32	537 02 01-01	Прокладка		1	1,37
33	537 02 02-01	КРЫШКА		1	1
34	537 02 07-01	SCREW		1	1
35	503 48 11-01	PIECE		1	1
36	503 47 96-01	SCREW		1	1
37	531 00 45-52	Набор прокладок	Set of gaskets	1	

J 135 R, 336 FR
CARBURETOR & AIRFILTER




Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 33 43-01	Патрубок входной		1	
2	537 37 12-02	Теплоизолятор		1	
3	537 37 11-01	Втулка		1	2
4	544 01 91-01	TUBULAR RIVET		1	2
5	537 37 38-03	TUBULAR RIVET		2	2
6	503 20 03-16	SCREW IHSCFM		2	
7	537 34 13-01	AIR DUCT		1	
8	575 72 90-01	Карбюратор	Zama C1Q-EL45	1	
9	503 21 75-50	SCREW IHSCFT		2	
10	503 49 71-01	Прокладка		1	
11	537 34 90-01	Привод дросселя		1	
12	544 37 27-01	SLEEVEING BRACKET		1	
13	575 84 18-01	Продукция		1	
14	537 21 32-09	KNOB		1	
15	575 86 37-02	FILTER HOLDER ASSY		1	
16	503 21 29-06	SCREW CCRPANT		2	15
17	575 84 15-01	Тяга в засл 3120K K1250		1	15
18	575 84 16-02	CHOKE LEVER		1	15
19	544 01 46-01	Привод дросселя		1	15
20	544 01 47-01	Воздуховод 371К		1	15
21	544 02 58-01	ЦЕПЬ ДЛЯ ХАРВЕСТЕРА		1	15
22	503 23 10-06	Шайба		1	
23	576 21 53-01	Крышка фильтра		1	
24	575 86 38-01	Рама		1	
25	503 20 03-20	SCREW IHSCFM		1	

F 135 R, 336 FR
CLUTCH




Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	574 84 29-01	Крышка стартера		1	
2	735 31 28-10	Шайба		1	1
3	738 21 01-04	Съемник подшипника		1	1
4	503 24 07-02	PARALLEL PIN		2	1
5	537 35 29-01	Барабан сцепления		1	
6	735 31 14-00	Шайба		1	
7	537 34 04-01	Сцепление		1	
8	537 42 72-01	Пружина		1	7
9	537 04 68-01	Шайба		1	
10	537 41 57-01	Шайба		1	
11	537 41 81-01	SCREW		2	
12	503 21 74-11	SCREW IHST		1	
13	537 32 27-01	ANTIVIBRATION ELEMENT		1	
14	537 31 01-01	COMPRESSION SLEEVE		1	
15	725 53 33-55	SCREW IHSCM		1	
16	575 86 58-01	КРЫШКА		1	
17	503 20 03-20	SCREW IHSCFM		3	
18	537 41 81-01	SCREW		3	

P 135 R, 336 FR
CRANKCASE



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	585 38 22-01	Коленвал		1	.
2	738 21 01-10	Съемник подшипника		2	1
3	503 26 02-02	SEALING RING		2	1
4	537 33 29-01	Прокладка		1	1
5	503 20 02-30	SCREW IHSCFM		4	1
6	501 27 08-01	Уплотнитель винта		2	1
7	537 32 42-01	Вкладыш		1	1

N 135 R, 336 FR
CRANK SHAFT






CRANKSHAFT

135 R

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	544 03 90-01	Коленвал		1	.
2	503 26 02-02	SEALING RING		2	1
3	738 21 01-10	Съемник подшипника		2	1
4	503 41 41-01	Подшипник		1	1

G 135 R, 336 FR
CYLINDER COVER




CYLINDER COVER

135 R


Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	575 86 50-01	Крышка цилиндра	Spare part with Captive Screw	1
2	573 99 43-05	SCREW IHSCFMO	Captiv Screw	1
3	575 86 57-01	Пластина	336 FR	1
4	503 20 03-02	SCREW IHSCFM		1
5	575 86 48-01	MUFFLERGUARD	Spare part with Captive Screw	1
6	574 47 70-03	SCREW IHSCFMO	Captiv Screw	2
7	576 99 86-14	Наклейка	336 FR	1
8	576 99 86-15	Наклейка	135 R	1
9	577 23 11-01	DAMPER	135 R	1

M 135 R, 336 FR
CYLINDER & PISTON



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	544 40 06-01	Цилиндр		1	.
2	585 99 83-02	Поршень с двумя кольцами		1	1
3	503 28 90-54	Кольцо поршневое		2	1,2
4	503 28 91-19	PISTON PIN		1	1,2
5	737 44 10-00	SNAP RING		2	1,2
6	503 41 41-01	Подшипник		1	1
7	725 53 33-55	SCREW IHSCM		4	1
8	537 33 30-02	Прокладка		1	


E 135 R, 336 FR
FUEL TANK



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	544 32 88-01	Топливный бак в сборе		1
2	503 91 10-01	Опора		4
3	544 88 97-01	Крышка топливного бака		1
3	544 88 97-03	Крышка топливного бака		1
4	503 93 66-01	PURGE		1
5	537 04 24-12	Шланг топливный		2
6	537 05 23-01	Шланг топливный		1
7	503 73 58-01	BUSHING		2
8	537 18 49-01	Сальник		1
9	503 44 32-01	Фильтр топливный с грузом		1


S DUO BALANCE 35
HARNESS

1




Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	537 27 57-02	ПОДВЕСКА КУСТОРЕЗА R		1	
1	537 27 57-04	ПОДВЕСКА КУСТОРЕЗА R	US	1	
2	537 28 83-01	FRONT PIECE		1	1
3	537 28 84-01	FRONT PIECE		1	1
4	537 27 59-01	Часть подвески кустореза		1	1
5	502 02 28-01	Отпускной крючок к рулет.		1	1
6	502 02 29-02	Отпускной крючок к рулет.		1	1,5
7	502 02 30-02	LOCK		1	1,5
8	586 34 10-01	Пружина		1	1,5
9	735 31 09-20	E-CLIP		1	1,5
10	503 99 61-01	Маркир.лента оранж/желтая		3	1
11	537 11 35-01	Держатель		1	1
12	503 99 61-03	Маркир.лента оранж/желтая		1	1

L 135 R, 336 FR, 336 FRD
IGNITION SYSTEM



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	537 24 96-01	Крыльчатка		1
2	731 71 16-51	HEXAGON NUT FLANGE		1
3	544 12 70-01	IGNITION MODULE		1
4	503 20 25-16	SCREW IHSCM		2
5	503 23 51-09	Свеча зажигания NGKBP7A		1
6	537 23 93-01	REPL BY 501 48 54-02		1

H 135 R, 336 FR
MUFFLER




MUFFLER

135 R

Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	505 40 86-01	MUFFLER ASSY	CAT	1	.
2	544 11 68-01	SPARK ARRESTER SCREEN		1	1
3	724 12 87-59	SCREW CRPANM		1	1
4	537 33 31-01	Прокладка		1	
5	537 34 08-01	AIR CONDUCTOR		1	
6	503 20 29-63	SCREW IHSCFM		2	
7	503 20 03-20	SCREW IHSCFM		1	


B2 135 R
SHAFT



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	501 91 97-01	TUBE ASSY		1	
2	537 21 41-01	TUBE		1	1
3	537 31 39-01	Направляющая		1	1
4	537 36 02-01	Втулка		1	1
5	537 36 02-02	Втулка		1	1
6	537 35 52-01	Вал 323HD 325HD		1	
7	537 13 04-03	KNOB		1	
8	725 23 31-51	SCREW		1	
9	505 16 10-01	Кольцо		1	9
10	537 35 01-01	Кольцо		1	
11	503 21 75-16	SCREW IHSCFT		1	
12	537 37 61-01	Тросик ледобура в сборе		1	
13	589 29 51-01	Наклейка		1	


T 135 R, 336 FR
SHORT BLOCK

1



Спр. №	Код	Описание	Замечание	КОЛ Наб.
1	585 38 23-01	SHORT BLOCK	Assembled	1

K1 135 R, 336 FR, 336 FRD
STARTER




STARTER

135 R


Спр. №	Код	Описание	Замечание	КОЛ Наб.	
1	575 84 08-01	Стартер в сборе Partner		1	
2	575 84 09-01	Крышка стартера 2095	Spare part adapted for captive screw	1	1
3	537 32 50-03	Катушка стартера		1	1
4	503 85 99-01	Пружина		1	1
5	503 21 88-76	SCREW IH SCT		1	1
6	503 23 00-80	Шайба		1	1
7	537 23 25-01	Ручка стартера		1	1
8	505 30 51-25	STARTER CORD		1	1
9	573 99 43-05	SCREW IH SCFMO	Captive screw	3	
10	577 22 36-01	Наклейка		1	
11	503 87 33-05	BRIDGE		1	
12	503 87 35-02	Собачка стартера		2	11
13	503 87 36-01	Пружина		2	11
14	735 31 08-20	E-CLIP		2	11

D 135 R, 336 FR
THROTTLE CONTROLS



Спр. №	Код	Описание	Замечание	КОЛ Наб.	
1	537 42 45-07	HANDLE SYSTEM		1	
2	537 16 02-03	Рукоятка	HARD GRIP, GREY	1	1
2	537 16 02-09	Рукоятка	SOFT GRIP, GREY + BLACK TPE	1	1
3	537 16 03-01	Рукоятка	HARD GRIP, GREY	1	1
3	537 16 03-02	Рукоятка	SOFT GRIP, GREY + BLACK TPE	1	1
4	503 22 10-13	HEXAGON NUT		1	1
5	537 35 96-02	Кабель 225H		1	
6	537 37 78-01	THROTTLE WIRE ASSY		1	5
7	503 21 66-18	SCREW IH SCT		1	5
8	503 87 85-07	Кабель 322, 323, 325, 326		1	5
9	537 41 90-01	MICRO SWITCH		1	1
10	506 49 77-01	THROTTLE CONTROL		1	1
11	537 17 42-01	SPRING THROTTLE TRIG		1	1
12	537 16 07-01	STARTER THROTTLE LOC		1	1
13	537 17 43-01	Пружина		1	1
14	503 21 66-18	SCREW IH SCT		2	1
15	503 20 07-35	SCREW IH SCFM		1	1
16	502 19 95-03	Рукоятка		1	
17	537 17 28-01	Передняя ручка 371K		1	
18	537 17 29-01	КРЫШКА		1	
19	731 23 14-01	HEXAGON NUT		1	
20	503 20 02-45	SCREW IH SCFM		1	
21	503 75 00-02	HANDLEBAR BRACKET		1	
22	502 21 12-01	Кронштейн 250PS		1	

C 135 R, 336 FR
TOWER



Спр. №	Код	Описание	Замечание	КОЛ	Наб.
1	576 27 74-01	HANDLEBAR BRACKET		1	
2	731 23 14-01	HEXAGON NUT		4	1
3	502 19 71-01	Гайка		1	1
4	502 28 61-01	CLAMP		1	
5	502 20 38-01	KNOB		1	
6	725 23 83-51	SCREW EHHM		1	
7	576 22 01-01	КРЫШКА		1	
8	576 22 00-01	COVER		1	
9	503 20 07-78	SCREW IHSCFM		4	